

BAE 146 P/N	DESCRIPTION	S/N	COND
0101KPR/2	INDICATOR,FUEL LOAD PRES.	XD7755	REP
0101KPR-2	INDICATOR,FUEL LOAD PRES.	XD6917	INS
0101KPR-2	INDICATOR,FUEL LOAD PRES.	XD6255	SV
0101KPR-2	INDICATOR,FUEL LOAD PRES.	XD7454	SV
0101KPU/2	PROCESSOR WING/CNTR F TNK	XD7403	REP
0101KPU-2	PROCESSOR WING/CNTR F TNK	XD7405	MOD
0101KPU-2	PROCESSOR WING/CNTR F TNK	XD6784	REP
0102KPU/2	PROCESSOR FEED TANK	XD7313	REP
0102KPU-2	PROCESSOR FEED TANK	XD6898	REP
0102KPU-2	PROCESSOR FEED TANK	XD6462	REP
0201KTU/10	GAUGING UNIT,FUEL TANK	TU100278	SV
0201KTU/11	GAUGING UNIT,FUEL TANK	964224	SV
0201KTU/13	GAUGING UNIT,FUEL TANK	TU110758	REP
0201KTU/15	GAUGING UNIT,FUEL TANK	TU113865	SV
0201KTU/15	GAUGING UNIT,FUEL TANK	TU111922	SV
0201KTU/16	GAUGING UNIT,FUEL TANK	TU111019	SV
0201KTU/18	GAUGING UNIT,FUEL TANK	TU115817	SV
0201KTU/29	GAUGING UNIT,FUEL TANK	TU120947	REP
0201KTU/31	TANK GAUGING UNIT	TU111220	SV
0201KTU/32	GAUGING UNIT,FUEL TANK	TU111244	SV
0201KTU/33	GAUGING UNIT,FUEL TANK	TU122156	SV
0201KTU/34	GAUGING UNIT,FUEL TANK	TU114022	SV
0201KTU/35	GAUGING UNIT,FUEL TANK	TU110827	REP
0201KTU14	GAUGING UNIT,FUEL TANK	TU110777	SV
0201KTU17	GAUGING UNIT,FUEL TANK	TU115779	SV
0201KTU19	GAUGING UNIT,FUEL TANK	TU100394	SV
0201KTU3	GAUGING UNIT,FUEL TANK	TU113534	REP
0201KTU33	GAUGING UNIT,FUEL TANK	TU110419	SV
0201KTU35	GAUGING UNIT,FUEL TANK	TU19758	REP
0201KTU35	GAUGING UNIT,FUEL TANK	TU110826	SV
05167-18340300	GUAGE, HYDRAULIC ACCUM (SASSY)	24460A	SV
064-1005-04	TRANSCEIVER,VHF COMM	7079	TST
064-1005-04	TRANSCEIVER,VHF COMM	6469	TST
064-1005-04	TRANSCEIVER,VHF COMM	10266	REP
064-1005-04	TRANSCEIVER,VHF COMM	6640	TST
064-1005-04	TRANSCEIVER,VHF COMM	10344	REP
064-1005-04	TRANSCEIVER,VHF COMM	6103	REP
066-1019-68	RECEIVER,DME	22352	SV
10060	SWITCH	314	INS
10060	SWITCH	209	INS
10060	SWITCH	F076	REP
10060	SWITCH	392	INS
10061	SWITCH	378	SV
10061	SWITCH	459	SV
10061	SWITCH	304	SV
10061	SWITCH	508	SV
10061	SWITCH	204	REP
10063	SWITCH	166	SV
10063	SWITCH	116	SV
10063	SWITCH	127	SV
100CC1-511	FAN,CABIN	492218	SV

101/17	OUTLET,WASTE WATER,HEATED	JECB017	FN
10113	SWITCH	256	REP
10113	SWITCH	298	SV
101-17	OUTLET,WASTE WATER,HEATED	JECB019	FN
101-17	OUTLET,WASTE WATER,HEATED	FF87-047	REP
101-17	OUTLET,WASTE WATER,HEATED	JECB013	FN
101-17	OUTLET,WASTE WATER,HEATED	FFDYHW-043 DUP	REP
101-17	OUTLET,WASTE WATER,HEATED	JECB018	FN
101-17	OUTLET,WASTE WATER,HEATED	WR39113	FN
10126A100-307	TAPE DECK	PL820	SV
10126A100-307D	TAPE DECK	PL-209	SV
10129	SWITCH,AIRSPEED	188	REP
10-1355-022111	UNIT, PASS SERVICE R/H	2587	SV
10-1355-022111	UNIT, PASS SERVICE R/H	2329	SV
10-1355-022121	PANEL,PASS SRVC R/H	2314	SV
10-1355-022121	PANEL,PASS SRVC R/H	2306	SV
10-1355-022121	PANEL,PASS SRVC R/H	1941	SV
10-1355-033121	PANEL,PASS SRVC L/H	1984	REP
10-1355-033121	PANEL,PASS SRVC L/H	2337	SV
10-1355-044111	PANEL ASSY,PSU	1044	REP
10-1355-044111	PANEL ASSY,PSU	0622	REP
10-1355-044121N	PANEL ASSY, PSU	1888	REP
10181	SWITCH	139	INS
10181	SWITCH	302	REP
102A-224-965	AC CONTROL PANEL COVER	CU9770	SV
102EL2BH	SENSOR,AIR TEMP	A56522	NEW
102LAA2	ACTUATOR,YAW DAMPER (SASSY)	1433	REP
103BA09	VALVE,FRESH WATER DRAIN	FRTR107/N	REP
103BA09	VALVE,FRESH WATER DRAIN	FRTR121/S	OVH
104273007	VALVE,NLG STEERING	DRG-9079-87	SV
104275001	ACTUATOR,UPLOCK	WEYDRG118/83	INS
104275001	ACTUATOR,UPLOCK	CWDD/DRG132/85	REP
104275001	ACTUATOR,UPLOCK	CWDDDRG9988	REP
104275001	ACTUATOR,UPLOCK	CWDD/DRG19/86	INS
104624001	JACK,FREE-FALL ASSISTER	DRG/4690/91	REP
104624001	JACK,FREE-FALL ASSISTER	DRG/119/85	REP
104625003	JACK, SIDESTAY {LFT} (SASSY)	DRG/11304/87	REP
104625004	JACK, SIDESTAY {RT} (SASSY)	CWDD/DRG/9/88	REP
104626001	JACK,NLG RETRACTION	DRG/82/83	REP
104626002	JACK,NLG RETRACTION	DRG5636/84	INS
104627003	JACK,OLEO LOCK, MLG {1,2,3}	DRG/6780/91	OVH
104627003	JACK,OLEO LOCK, MLG {1,2,3}	DRG/5865/88	OVH
104627003	JACK,OLEO LOCK, MLG {1,2,3}	DRG/5866/88	OVH
104733003	VALVE,SHUTOFF,NLG (SASSY)	CWDDDRG286	OVH
104751002	VALVE,MLG RESTRICTOR	MSA.663.01	SV
104753001	VALVE,NLG RESTRICTOR	CWDD/DRG10/91	REP
104753001	VALVE,NLG RESTRICTOR	CWDD/DRG1181	REP
104753001	VALVE,NLG RESTRICTOR	CWDDDRG380	REP
10-536-1	SPLITTER	337	SV
10-537-1	DISTRIBUTOR	228	SV
10-537-1	DISTRIBUTOR	113	SV
109812-9	VALVE,APU LOAD CONTROL(SASSY)	2272	SV

109812-9	VALVE,APU LOAD CONTROL(SASSY)	1959	SV
109812-9	VALVE,APU LOAD CONTROL(SASSY)	332C	REP
109812-9	VALVE,APU LOAD CONTROL(SASSY)	2415	REP
109812-9-1	VALVE,APU LOAD CONTROL(SASSY)	P-122C	SV
109812-9-1	VALVE,APU LOAD CONTROL(SASSY)	263C	SV
109812-9-1	VALVE,APU LOAD CONTROL(SASSY)	1124C	REP
109812-9-1	VALVE,APU LOAD CONTROL(SASSY)	1058C	REP
109812-9-1	VALVE,APU LOAD CONTROL(SASSY)	P-120C	REP
110RAA3	SERVO MOTOR PITCH	2325	OVH
110RAA4	SERVO MOTOR TRIM	2361	SV
114.056	AMMETER,AC	84080191	SV
114.058	INDICATOR,FUEL TEMP	84030051	SV
114.058	INDICATOR,FUEL TEMP	84060074	OVH
114.059	INDICATOR,DUCT TEMP	84030093	OVH
114.06	INDICATOR,DISCHARGE VALVE	86020225	OVH
114.062	AMMETER,BATTERY	83080035	SV
114.062	AMMETER,BATTERY	84030046	SV
114.063-1	INDICATOR,FUEL QTY	86120149	REP
114.063-1	INDICATOR,FUEL QTY	87070398	INS
114.158	INDICATOR,ROLL SPOILER	84030029	OVH
114.158	INDICATOR,ROLL SPOILER	86030153	REP
114.158	INDICATOR,ROLL SPOILER	81D0020M	MOD
114-054	AMMETER,DC	84060143	OVH
114-054	AMMETER,DC	84070167	OVH
114-054	AMMETER,DC	83050085	SV
114-054	AMMETER,DC	84100187	SV
114-056	AMMETER,AC	83080107	SV
114.058	INDICATOR,FUEL TEMP	83020026	REP
114-058	INDICATOR,FUEL TEMP	84080094	OVH
114-059	INDICATOR,DUCT TEMP	86100248	SV
114-060	INDICATOR,DISCHARGE VALVE	82010050	OVH
114-062	AMMETER,BATTERY	84060070	SV
114.158	INDICATOR,ROLL SPOILER	83020027	SV
115.024	INDICATOR,CABIN TEMP	84020046	SV
115.026	INDICATOR,HYD PRESSURE	83030056	OVH
115.026	INDICATOR,HYD PRESSURE	84050146	REP
115.033	VOLTMETER DC	83030029	SV
115.033	VOLTMETER DC	80B0003	SV
115.033	VOLTMETER DC	82010023	SV
115.034	VOLTMETER,AC	83080035	SV
115.035	METER,FREQUENCY	83090042	SV
115.035	METER,FREQUENCY	84080077	SV
115.221	INDICATOR,HYD QTY	83030005	SV
115.221	INDICATOR,HYD QTY	83120027	SV
115.25	VOLTMETER	88110099	REP
115.024	INDICATOR,CABIN TEMP	84060051	OVH
115-026	INDICATOR,HYD PRESSURE	84050101	TST
115.034	VOLTMETER,AC	84060057	REP
12350-3	SWITCH,PRESS,HYD/STALL WARN	0391TW	NEW
12350-3	SWITCH,PRESS,HYD/STALL WARN	0273TW	NEW
12350-3	SWITCH,PRESS,HYD/STALL WARN	0392TW	NEW
124.183	INDICATOR,OAT	81D0009	REP

124.593-2	INDICATOR,FLAP POSITION	84050008	REP
124.593-2	INDICATOR,FLAP POSITION	84050013	REP
124.593-2	INDICATOR,FLAP POSITION	84050011	REP
124.593-2	INDICATOR,FLAP POSITION	84050024	REP
124.593-2	INDICATOR,FLAP POSITION	83040100	REP
124.593-2	INDICATOR,FLAP POSITION	88080213	REP
124.620-1	INDICATOR,EGT	81100001	OVH
124.621-1	INDICATOR,RPM	81100007	INS
124.621-2	INDICATOR,RPM	88080001	REP
124-181-1	INDICATOR,BRAKE PRESSURE	87030253	OVH
124-181-1	INDICATOR,BRAKE PRESSURE	84060111	OVH
124-183	INDICATOR,OAT	88030159	OVH
124-183	INDICATOR,OAT	88010156	OVH
124-620-2	INDICATOR,EGT	89050184	INS
12529-2	SWITCH, LOW PRSSURE (SASSY)	0049TW	INS
12530-2	SWITCH (SASSY)	0288TW	TST
12530-2	SWITCH (SASSY)	0378TW	INS
12530-2	SWITCH (SASSY)	0096	INS
1295R000	DISCONNECT UNIT,AILERON	730604-6	REP
1344D000-002	AIR CYCLE MACHINE (SASSY)	A566838-2	SV
1344D000-002	AIR CYCLE MACHINE (SASSY)	499920-7	REP
150706002	VALVE	CWDDDRG2843	TST
15201-2	SWITCH,LOW PRESSURE	0537TW	INS
15201-2	SWITCH,LOW PRESSURE	0720TW	NEW
15201-2	SWITCH,LOW PRESSURE	0102TW	INS
15201-2	SWITCH,LOW PRESSURE	0798TW	NEW
154615-3-1	VALVE,OIL TEMP CONTROL (SASSY)	117-426	OVH
154615-3-1	VALVE,OIL TEMP CONTROL (SASSY)	114-186	OVH
154615-3-1	VALVE,OIL TEMP CONTROL (SASSY)	115-322	INS
154615-3-1	VALVE,OIL TEMP CONTROL (SASSY)	107-417	INS
154615-3-1	VALVE,OIL TEMP CONTROL (SASSY)	107-409	INS
160052-1	OIL COOLER (SASSY)	27-649	SV
160052-1	OIL COOLER (SASSY)	87-711	SV
160052-1	OIL COOLER (SASSY)	101-177	OVH
160052-1	OIL COOLER (SASSY)	96-609	SV
160052-1	OIL COOLER (SASSY)	46-561	OVH
160052-1	OIL COOLER (SASSY)	58-828	INS
160052-1	OIL COOLER (SASSY)	103-257	INS
160052-1	OIL COOLER (SASSY)	115-503	INS
160052-1	OIL COOLER (SASSY)	38-785	INS
160052-1	OIL COOLER (SASSY)	73-231	INS
160122-1	OIL COOLER,APU	28-313	SV
160122-1	OIL COOLER,APU	19-363	SV
1703-12	VANE,ANGLE OF ATTACK	307	SV
1703-12	VANE,ANGLE OF ATTACK	244	SV
1703-12	VANE,ANGLE OF ATTACK	811	SV
1703-12	VANE,ANGLE OF ATTACK	546	SV
1703-12	VANE,ANGLE OF ATTACK	125	SV
17127	SWITCH,AIRSPEED	F012	SV
172938-001	LEDEX RELAY	9430	SV
172938-001	LEDEX RELAY	5010	SV
17960-0102-0012	CONTROL DISPLAY UNIT	M1629	REP

17960-0102-0012	CONTROL DISPLAY UNIT	2700	REP
17960-0102-0012	CONTROL DISPLAY UNIT	M1259	REP
17960-0102-0012	CONTROL DISPLAY UNIT	M1521	REP
17960-0102-0012	CONTROL DISPLAY UNIT	M1552	REP
185.102-1	INDICATOR,OIL TEMP & PRES	83050011	SV
185.102-1	INDICATOR,OIL TEMP & PRES	84050082	SV
185-102-1	INDICATOR,OIL TEMP & PRES	88110644	SV
187830/002	SEAT,CO-PILOT	9500005	SV
188949	CABLE ASSY, CONTROL (SASSY)	20050004	SV
188949	CABLE ASSY, CONTROL (SASSY)	20050006	SV
188949	CABLE ASSY, CONTROL (SASSY)	95015981	INS
188949	CABLE ASSY, CONTROL (SASSY)	1245/91	INS
1U453-001	CONTROLLER,COMM	126	REP
1U453-001	CONTROLLER,COMM	T302A	REP
1U453-001	CONTROLLER,COMM	T196A	REP
1U453-001	CONTROLLER,COMM	T283A	REP
1U456-001	CONTROLLER,ADF	123	SV
1U456-001	CONTROLLER,ADF	T191	REP
1U456-001	CONTROLLER,ADF	T183	REP
1U458-001	CONTROLLER,TRANSPONDER	112	SV
1U458-001	CONTROLLER,TRANSPONDER	T375A	SV
1U458-001	CONTROLLER,TRANSPONDER	120	SV
1U458-001	CONTROLLER,TRANSPONDER	T195A	SV
1U458-001	CONTROLLER,TRANSPONDER	115	SV
1U458-001	CONTROLLER,TRANSPONDER	108	SV
1U458-001	CONTROLLER,TRANSPONDER	125	SV
1U460-001	SELECTOR,AUDIO	T334	REP
1U461-001	VHF NAV/DME CONTROLLER	T135A	SV
1U471-001	SELECTOR,AUDIO	T372	REP
1U471-001	SELECTOR,AUDIO	T315	REP
200662002	BOX,DFRNTL STEERING	DRG/1428/85	SV
200671311	AXLE, MLG {2} (SASSY)	MSA - 750-98	OVH
200876279	HARNESS	NA	NEW
200876287	TORQUE LINK	NA	SV
200876287	TORQUE LINK	NA	SV
200876287	TORQUE LINK	NA	SV
200876287	TORQUE LINK	NA	SV
200877206	LEVER,DIR CRANK LH{123}(SASSY)	DAAS/40/95	SV
200877668	PIN,DIR CRANK {1,2,3} (SASSY)	23163/92	SV
200877682	PIN,SHK ABS,LOW {1,2}(SASSY)	DAAS/2077/95	SV
200883001	KIT	DRG-5038-89	SV
200884004	SIDESTAY,RH MLG{1,2} (MASSY)	DRG/2755/85	SV
200884217	HARNESS,LH DWNLOCK SENSOR	20084217	SV
200884243	HARNESS,LH DWNLOCK SENSOR	NA	SV
200884243	HARNESS,LH DWNLOCK SENSOR	NA	SV
200884245	HARNESS,RH DWNLOCK SENSOR	NA	SV
200885003	UPLOCK, ASSY, MLG LH	CWDD/DRG4/84	SV
200885004	UPLOCK, ASSY, MLG RH	CWDD/DRG37/85	INS
200895001	ABSORBER, SHOCK, MLG {1,2}	DRG/3907/86	SV
200895001	ABSORBER, SHOCK, MLG {1,2}	DRG/8745/88	SV
200895001	ABSORBER, SHOCK, MLG {1,2}	DRG/733/82	SV
200898004	ACTUATOR ASSY,RH DOOR UPL	CWDD/DRG2/86	SV

200915254	LINK ASSY,DIRECTION MLG{1,2,3}	543935	SV
201077205	CRANK,DIRECTIONAL RH MLG{1,2}	HAS/94	SV
201105004	SIDESTAY,RH MLG{1,2,3} (MASSY)	DRG/3962/89	SV
201105004	SIDESTAY,RH MLG{1,2,3} (MASSY)	DRG/24/89	SV
201106001	ABSORBER, SHOCK MLG{1,2,3}	M-DG-0175	OVH
201106001	ABSORBER, SHOCK MLG{1,2,3}	DRG/1394/87	REP
201106001	ABSORBER, SHOCK MLG{1,2,3}	DRG/5929/89	OVH
201107615	PIN,SHK ABS,LOW {1,2,3}(SASSY)	9808-94	SV
201109217	HARNESS,R/H MLG	NA	SV
201138002	LEG,NLG {2,3} (MASSY)	DRG/6853/89	OVH
2-013-000-07RP8	TAILPIPE,EXHAUST (SASSY)	55	SV
2-013-000-07RP8	TAILPIPE,EXHAUST (SASSY)	JLDH0046	SV
2-013-000-08	TAILPIPE,EXHAUST (SASSY)	8204064NBW	SV
2-013-000-08RP8	TAILPIPE,EXHAUST (SASSY)	64	SV
2-013-000-12	TAILPIPE,EXHAUST (SASSY)	JLDH0393	SV
2-013-000-12	TAILPIPE,EXHAUST (SASSY)	JLDH-0375	SV
2-013-000-12	TAILPIPE,EXHAUST (SASSY)	JLDH-0537	SV
2-013-000-12	TAILPIPE,EXHAUST (SASSY)	JLDH0305	SV
2-013-000-12RP8	TAILPIPE,EXHAUST (SASSY)	JLDH-0535	SV
201423200	CRANK,DIRECTIONAL LH MLG{1,2,3}	9995/91	REP
2022550-5-3	ACTUATOR,T.MNGMNT SYSTEM	46-577	INS
2022550-5-3	ACTUATOR,T.MNGMNT SYSTEM	46-585	REP
2022550-5-3	ACTUATOR,T.MNGMNT SYSTEM	14-243	REP
2022550-5-3	ACTUATOR,T.MNGMNT SYSTEM	19-1088	REP
2022550-5-3	ACTUATOR,T.MNGMNT SYSTEM	106-639	REP
2022550-5-3	ACTUATOR,T.MNGMNT SYSTEM	41-1540	REP
2022550-5-3	ACTUATOR,T.MNGMNT SYSTEM	93-1801	REP
2022550-5-3	ACTUATOR,T.MNGMNT SYSTEM	41-1536	REP
203SUM1	SENSOR,HEIGHT	AD682	REP
203SUM1	SENSOR,HEIGHT	AD859	REP
209RAA5-7BAE	MOUNTING,ELEV TRIM SERVO	C1054	OVH
209RAA6-135CAF	MOUNTING,PITCH SERVO	C1166	OVH
209RAA6-175ABC	MOUNTING, PITCH SERVO	1662	SV
209RAA6-8CEF	MOUNTING, AILERON SERVO	1565	OVH
20SCRT1S1K200G	TRANSDUCER,OIL PRESSURE(SASSY)	4648-4-351	SV
210044-101	SEAT, LH DOUBLE	1094	SV
210044-201	SEAT RH TRIPLE 300 SERIES	NA	SV
2117404-4	CONTROL UNIT,ELECTRONIC	52-450	SV
2117404-5	CONTROL UNIT,ELECTRONIC	72-477	SV
2117404-5	CONTROL UNIT,ELECTRONIC	100-235	SV
2117404-5	CONTROL UNIT,ELECTRONIC	63-572	SV
2117404-5	CONTROL UNIT,ELECTRONIC	64-646	SV
2117404-5	CONTROL UNIT,ELECTRONIC	41-348	SV
2117404-5	CONTROL UNIT,ELECTRONIC	123-614	SV
2117576-3	DISPLAY,THRUST MANAGEMENT	46-241	REP
2117576-3	DISPLAY,THRUST MANAGEMENT	23-134	REP
2117576-3	DISPLAY,THRUST MANAGEMENT	18-284	REP
2117578-9	COMPUTER,THRUST MANAGEMNT(MSA)	21-101	REP
2117578-9	COMPUTER,THRUST MANAGEMNT(MSA)	65-238	SV
2117578-9	COMPUTER,THRUST MANAGEMNT(MSA)	42-118	REP
2117608-1	SWITCH,THRUST MANAGEMENT	125-220	REP
2117608-1	SWITCH,THRUST MANAGEMENT	18-279	REP

2117608-1	SWITCH,THRUST MANAGEMENT	32-130	SV
2118770-1	ECU	19-142	SV
21B107-6-A	CONTROL,STNDBY GNRTR,XH1	124	REP
21M27-13	SWITCH,FLOW INDICATOR	D043030A	REP
21M27-13	SWITCH,FLOW INDICATOR	D107A	REP
21M27-23	SWITCH,OVERPRESSURE	E022772	INS
21M27-24	SWITCH,FLOW INDICATOR	F005600	INS
21M27-4	SWITCH,OVERPRESSURE	E212A	REP
21M27-4	SWITCH,OVERPRESSURE	G186A	REP
21M27-4	SWITCH,OVERPRESSURE	H233A	REP
21M27-4	SWITCH,OVERPRESSURE	K207A	INS
21M27-4	SWITCH,OVERPRESSURE	K122A	SV
21M27-4	SWITCH,OVERPRESSURE	M194A	SV
21M27-4	SWITCH,OVERPRESSURE	E139A	REP
21M27-4	SWITCH,OVERPRESSURE	G102A	SV
21M27-4	SWITCH,OVERPRESSURE	K169A	SV
21M27-4	SWITCH,OVERPRESSURE	G226A	REP
2202-1100-00	MADRAS DFDR (MASSY)	105	INS
2202-1100-00	MADRAS DFDR (MASSY)	00102	REP
22504-13	VALVE	247	REP
2313M-158-1	WIPER,R/H MOTOR	0648	REP
2313M-158-1	WIPER,L/H MOTOR	0596	REP
2313M-158-1	WIPER,L/H MOTOR	0713	REP
2313M158-2	WIPER,R/H MOTOR	00762	SV
2351A000	VALVE,ICE/RAIN P.REDUC (SASSY)	C280138-5	SV
251561	CONDUIT,POWER LEVER	15565	INS
251561	CONDUIT,POWER LEVER	15566	INS
251561	CONDUIT,POWER LEVER	15569	INS
2542A000	SWITCH,APU DUCT PRESSURE	346446-2	INS
2542A000	SWITCH,APU DUCT PRESSURE	237013-2	SV
2587335-114	GYRO, VERTICAL	85015112	REP
2587335-114	GYRO, VERTICAL	86125902	REP
2587335-114	GYRO, VERTICAL	84115059	REP
2587335-114	GYRO, VERTICAL	89026763	REP
2587335-114	GYRO, VERTICAL	88126721	REP
2587335-114	GYRO, VERTICAL	86125903	REP
2587335-114	GYRO, VERTICAL	87015950	REP
2588317-925	COMPARATOR,MONITOR INSTR.	88033427	SV
2589419-901	VALVE,FLUX	87084358	SV
2589419-901	VALVE,FLUX	91098333	SV
2591200-901	COMPENSATOR,MAGNETIC	88035038	SV
2591200-901	COMPENSATOR,MAGNETIC	81074152	SV
2591201-903	COUPLER,COMPASS	89097711	REP
2591201-903	COUPLER,COMPASS	84106270	REP
2591201-903	COUPLER,COMPASS	86076873	REP
2591201-903	COUPLER,COMPASS	89017633	REP
2594661-803	RADIO MAG INDICATOR	85020941	SV
2594860-901	GYRO,DIRECTIONAL	85110749	REP
2594860-901	GYRO,DIRECTIONAL	84090673	INS
2594860-901	GYRO,DIRECTIONAL	89040992	REP
2594860-901	GYRO,DIRECTIONAL	81010558	REP
2635A000	SWITCH,FLOW INDICATION	031	REP

2635A000	SWITCH,FLOW INDICATION	724900-6	REP
2635A000	SWITCH,FLOW INDICATION	172	REP
2635A000	SWITCH,FLOW INDICATION	ID4943	REP
2764A000	VALVE DISCHARGE 300	B405642-3	REP
2764A000	VALVE DISCHARGE 300	A722326-2	REP
2766A000	LIMITER ALTITUDE	726386-12	SV
2767A170	POTMETER RATE	8938365	SV
2767A300	PCB CONTROL	989146-6	SV
2767A310	PCB CONTROL	090634-2	SV
2767A320	PCB POWER	167418-1	SV
2783A000	CONTROLLER,PRESS.SELECTOR	A790849-1	INS
2783A000	CONTROLLER,PRESS.SELECTOR	F291371-6	REP
2783A000	CONTROLLER,PRESS.SELECTOR	B753187-3	REP
2783A020	PANEL SUBASSY	212243-3	SV
2LA003-666-00	LAMP	177	SV
30-0837-27	BEACON ASY,ANTI COLLISION	4502	INS
30-0837-27	BEACON ASY,ANTI COLLISION	4501	INS
30-0837-27	BEACON ASY,ANTI COLLISION	1645	SV
30-1401-13	BEACON ASY,ANTI COLLISION	1597	SV
30-1401-13	BEACON ASY,ANTI COLLISION	1764	SV
30-1401-13	BEACON ASY,ANTI COLLISION	54	SV
30-1401-13	BEACON ASY,ANTI COLLISION	3589	SV
30-1401-13	BEACON ASY,ANTI COLLISION	4B	SV
30-1401-13	BEACON ASY,ANTI COLLISION	0026A	SV
3015B000	VALVE,NON RETURN	395620-12	REP
3015B000	VALVE,NON RETURN	374163-2	SV
3015B000	VALVE,NON RETURN	040841/1	REP
3015B000	VALVE,NON RETURN	653109-1	SV
30-1809-1	LIGHT ASSY,STROBE,WING	740	SV
30-1809-1	LIGHT ASSY,STROBE,WING	224	SV
301ADA/FA/1	ACCELEROMETER,LATERAL	AG618	SV
301ADA/FA/1	ACCELEROMETER,LATERAL	AH141	SV
30-231-15	DETECTOR, SMOKE	28131	REP
306-4313	SWITCH	0667	INS
306-4313	SWITCH	0451	SV
306-4313	SWITCH	0328	SV
306-4313	SWITCH	0632	SV
3081B000	VALVE,NON-RETURN	017973-5	SV
3081B000	VALVE,NON-RETURN	461938-5	REP
3081B000	VALVE,NON-RETURN	339241-4	REP
3101-08	DETECTOR,ENGINE FIRE	4167	SV
3101-08	DETECTOR,ENGINE FIRE	5134	SV
3101-08	DETECTOR,ENGINE FIRE	13436	REP
3101-08	DETECTOR,ENGINE FIRE	14773	INS
3101-08	DETECTOR,ENGINE FIRE	14418	INS
3101-08	DETECTOR,ENGINE FIRE	14882	INS
3101-08	DETECTOR,ENGINE FIRE	2135	REP
3101-09	DETECTOR,ENGINE FIRE (SASSY)	14155	AR
3101-09	DETECTOR,ENGINE FIRE (SASSY)	8595	SV
3101-09	DETECTOR,ENGINE FIRE (SASSY)	14118	SV
3101-09	DETECTOR,ENGINE FIRE (SASSY)	15182	COFC
3101-09	DETECTOR,ENGINE FIRE (SASSY)	15184	COFC

3101-09	DETECTOR,ENGINE FIRE (SASSY)	14539	SV
3101-09	DETECTOR,ENGINE FIRE (SASSY)	15181	COFC
3101-09	DETECTOR,ENGINE FIRE (SASSY)	15076	COFC
3101-09	DETECTOR,ENGINE FIRE (SASSY)	14969	NEW
3101-09	DETECTOR,ENGINE FIRE (SASSY)	12546	SV
3101-09	DETECTOR,ENGINE FIRE (SASSY)	10399	AR
3101-09	DETECTOR,ENGINE FIRE (SASSY)	13355	SV
3101-09	DETECTOR,ENGINE FIRE (SASSY)	12630	SV
3101-09	DETECTOR,ENGINE FIRE (SASSY)	13924	SV
3101-09	DETECTOR,ENGINE FIRE (SASSY)	13124	SV
3101-09	DETECTOR,ENGINE FIRE (SASSY)	11673	SV
3101-09	DETECTOR,ENGINE FIRE (SASSY)	12469	SV
3101-09	DETECTOR,ENGINE FIRE (SASSY)	12569	AR
3101-09	DETECTOR,ENGINE FIRE (SASSY)	13552	INS
3101-09	DETECTOR,ENGINE FIRE (SASSY)	14662	INS
3101-09	DETECTOR,ENGINE FIRE (SASSY)	14900	INS
3101-09	DETECTOR,ENGINE FIRE (SASSY)	13356	INS
3101-10	DETECTOR,APU FIRE	7654	SV
3101-10	DETECTOR,APU FIRE	1894	SV
3101-10	DETECTOR,APU FIRE	14819	SV
3300	SUPPRESSOR, AC PUMP RIPPLE	APC194	SV
3335B000	VALVE,NON-RETURN	364408-1	REP
3335B000	VALVE,NON-RETURN	849006/2	REP
35008-13	CONTROLLER,OVERHEAT CFD	B1277	REP
35008-13	CONTROLLER,OVERHEAT CFD	B617	SV
35008-13	CONTROLLER,OVERHEAT CFD	B1091	SV
3502B000-003	VALVE ,F.CNTRL/SHTOFF ISO.	558240-7	REP
3502B000-003	VALVE ,F.CNTRL/SHTOFF ISO.	RA458356-7	REP
3502B000-003	VALVE ,F.CNTRL/SHTOFF ISO.	C297272-5	REP
3503B000	VALVE	268442-9	REP
3503B000	VALVE	591552-3	REP
3503B000	VALVE	A743054/1	REP
3508000/282	INDICATOR,FUEL LEVEL	FRTR101/L	SV
3508000/282	INDICATOR,FUEL LEVEL	FRTR100/L	SV
3508000/283	INDICATOR,FUEL LEVEL	FRTR120/K	SV
3515000/241	SWITCH,FLOAT	FRTR766/S	OVH
3515000/241	SWITCH,FLOAT	FRTR674/R	OVH
3537B000	VALVE,MODE SELECTOR	645481	SV
3545H7	SERVO, RUDDER	7YH168190	SV
3545H7	SERVO, RUDDER	7YH166463	SV
3550B000	VALVE,DUCT PRESS RELIEF	B916218-1	REP
3550B000	VALVE,DUCT PRESS RELIEF	916218-4	SV
3550B000	VALVE,DUCT PRESS RELIEF	A770518/5	REP
3550B000	VALVE,DUCT PRESS RELIEF	401854-5	REP
3551H1	FILTER BOWL ASSY	FYH188084	REP
3551H1	FILTER BOWL ASSY	FYH182180	REP
3559B000	VALVE, NON-RETURN (SASSY)	045275-1	REP
3610004-3	NOZZLE PRIMARY (SASSY)	0178	SV
3610004-3	NOZZLE PRIMARY (SASSY)	0727	SV
3610004-3	NOZZLE PRIMARY (SASSY)	0636	SV
3610004-4	NOZZLE SECONDARY (SASSY)	1PL04189	SV
3610004-4	NOZZLE SECONDARY (SASSY)	4350	SV

3610004-4	NOZZLE SECONDARY (SASSY)	0338	SV
3706270	VALVE,SOLENOID	FR077BC	FN
3706270	VALVE,SOLENOID	FR027BG	NEW
3799H1	VALVE, AIRBRAKE	FYH144505	REP
3799H1	VALVE, AIRBRAKE	FYH164159	REP
3819H6	SERVO, ROLL SPOILER	FYH130746	SV
3819H6	SERVO, ROLL SPOILER	FYH134736	SV
383-0001-1	HOT PLATE	0684	SV
3830061-5	NOZZLE ASSY,APU FUEL (SASSY)	4337	SV
3830061-5	NOZZLE ASSY,APU FUEL (SASSY)	1381	SV
3830061-5	NOZZLE ASSY,APU FUEL (SASSY)	5491	SV
3830061-5	NOZZLE ASSY,APU FUEL (SASSY)	1SL03681	SV
3830061-5	NOZZLE ASSY,APU FUEL (SASSY)	1PV04696	SV
3830061-5	NOZZLE ASSY,APU FUEL (SASSY)	1SV05968	SV
3830061-5	NOZZLE ASSY,APU FUEL (SASSY)	3307	SV
3830061-5	NOZZLE ASSY,APU FUEL (SASSY)	5026	SV
3830061-5	NOZZLE ASSY,APU FUEL (SASSY)	6179	SV
3830061-5	NOZZLE ASSY,APU FUEL (SASSY)	1RS06682	SV
3830061-5	NOZZLE ASSY,APU FUEL (SASSY)	257	SV
3830061-5	NOZZLE ASSY,APU FUEL (SASSY)	6171	SV
3830077-7	COMBUSTION CHAMBER,APU (SASSY)	92PA-023	SV
3830077-8	COMBUSTION CHAMBER APU	GA1	SV
3830077-9	COMBUSTION CHAMBER,APU (SASSY)	P-283E	SV
3830077-9	COMBUSTION CHAMBER,APU (SASSY)	61013	SV
3830077-9	COMBUSTION CHAMBER,APU (SASSY)	113645	SV
3846004-7	SCHROLL	NA	SV
3846096-1	PLENUM,APU	NA	SV
3846096-1	PLENUM,APU	NA	SV
3846096-1	PLENUM,APU	NA	SV
3860198-3	CLUTCH ASSY,APU	NA	SV
3860198-3	CLUTCH ASSY,APU	NA	SV
3862200-3	FAN ASSY (SASSY)	P-147C	SV
3862200-3	FAN ASSY (SASSY)	P-512C	SV
3882600-8	FUEL CONTROL,APU (SASSY)	A-513C	SV
3882600-8	FUEL CONTROL,APU (SASSY)	A1063C	SV
3882600-8	FUEL CONTROL,APU (SASSY)	A-1231C	SV
3882600-8-1	FUEL CONTROL,APU (SASSY)	A762C	SV
3882730-9	FUEL CONTROL,APU (SASSY)	27288	SV
3882730-9	FUEL CONTROL,APU (SASSY)	16015	SV
3884569-6	VALVE,APU SURGE SHUTOFF(SASSY)	0261	SV
3888000-2	IGNITOR UNIT,APU (SASSY)	010218020448	SV
3888000-2	IGNITOR UNIT,APU (SASSY)	010218029245	SV
3888000-2	IGNITOR UNIT,APU (SASSY)	000218017707	SV
3888134-4	VALVE,SOLENOID-100APU (SASSY)	00-714	RUS
4019700-902	INDICATOR,ATTITUDE DRCTNL	85100817	SV
4019700-902	INDICATOR,ATTITUDE DRCTNL	88051259	SV
4019700-902	INDICATOR,ATTITUDE DRCTNL	84080573	SV
4019700-902	INDICATOR,ATTITUDE DRCTNL	81110290	SV
401RGU/FA/2	SENSOR,SINGLE RATE GYRO	AE256	SV
401RGU-FA2	SENSOR,SINGLE RATE GYRO	AE558	SV
401RGU-FA2	SENSOR,SINGLE RATE GYRO	AE309	SV
4034559-901	INDICATOR,DBI	83120772	SV

4034559-901	INDICATOR,DBI	87062017	SV
4034559-902	INDICATOR,DBI	88032356	SV
4037539-906	INDICATOR,HSI	84120314	SV
4037539-906	INDICATOR,HSI	83070268	SV
4037539-906	INDICATOR,HSI	86030357	SV
4037539-906	INDICATOR,HSI	84090299	SV
4045147-906	INDICATOR,HSI	82090174	SV
4066453-902	TRIM CLUTCH	88090101	REP
407/1/32460/000	TRANSFORMER,CURRENT	TEO578	INS
407/1/32460/000	TRANSFORMER,CURRENT	TAB1514	TST
4101H2	SERVO,ROLL SPOILER	FYH165840	SV
4101H2	SERVO,ROLL SPOILER	FYH164453	SV
416-0001-25	COFFEE MAKER	1105	SV
416-0001-25	COFFEE MAKER	0046	SV
416-0001-25	COFFEE MAKER	0024	SV
416-0001-35	COFFEE MAKER	0107	SV
416-0001-35	COFFEE MAKER	0402	SV
416-0201-11	RAIL ASSEMBLY	NA	SV
416-0201-11	RAIL ASSEMBLY	NA	SV
416-0201-11	RAIL ASSEMBLY	NA	SV
416-1001-25	COFFEE MAKER	0060	SV
416-1001-25	COFFEE MAKER	0779	SV
416-1001-25	COFFEE MAKER	0560	SV
416-1001-25	COFFEE MAKER	0524	SV
4177-0047-3	DIPSTICK	NA	SV
4177-0047-3	DIPSTICK	NA	SV
4177-0047-3	DIPSTICK	NA	SV
4177-0047-3	DIPSTICK	NA	SV
4177-0047-3	DIPSTICK	NA	SV
4204002	UNIT, POWER TRANSFER/PTU	NA58	SV
4325C000	CONTROLLER,TEMPERATURE	395688-4	SV
4325C000	CONTROLLER,TEMPERATURE	341400-2	SV
4325C000	CONTROLLER,TEMPERATURE	843172-1	SV
4353C000	PRECOOLER	268253-2	SV
4353C000	PRECOOLER	325745-9	SV
4353C000	PRECOOLER	A322016-4	SV
4372C000	SENSOR,DUCT TEMPERATURE	511124-46	SV
43731-589-0	CIRCUIT BOARD,PRINTED	1043	SV
43731-589-0	CIRCUIT BOARD,PRINTED	1038	SV
43731-589-0	CIRCUIT BOARD,PRINTED	1075	SV
43731-589-0	CIRCUIT BOARD,PRINTED	1010	SV
4373C000	SENSOR,CABIN TEMPERATURE	099391-4	SV
4373C000	SENSOR,CABIN TEMPERATURE	314549-9	SV
4373C000	SENSOR,CABIN TEMPERATURE	64583-11	SV
446290	CARTRIDGE, FIRE BOTTLE (SASSY)	010401012 HAZMAT	SV
446290D	CARTRIDGE, FIRE BOTTLE (SASSY)	03014 HAZMAT	SV
448D100-1	HANDSET,FLIGHT ATTENDANT	1047A	SV
448D100-1	HANDSET,FLIGHT ATTENDANT	1067	SV
448D100-1	HANDSET,FLIGHT ATTENDANT	1047	SV
448D100-1	HANDSET,FLIGHT ATTENDANT	1033	SV
448D100-1	HANDSET,FLIGHT ATTENDANT	1092	SV
448D100-1	HANDSET,FLIGHT ATTENDANT	1065	SV

448D100-1	HANDSET,FLIGHT ATTENDANT	1101	SV
448D100-1	HANDSET,FLIGHT ATTENDANT	1051	SV
448D300-1	HANDSET,FLIGHT ATTENDANT	1216	SV
448D300-1	HANDSET,FLIGHT ATTENDANT	1008	SV
448D300-1	HANDSET,FLIGHT ATTENDANT	1199	SV
448D300-1	HANDSET,FLIGHT ATTENDANT	1112	SV
46546-509-0	CIRCUIT BOARD,PRINTED	1073	SV
46546-509-0	CIRCUIT BOARD,PRINTED	1070	SV
46546-510-0	CIRCUIT BOARD,PRINTED	1067	SV
46546-513-0	CIRCUIT BOARD,PRINTED	1195	SV
46546-513-0	CIRCUIT BOARD,PRINTED	1573	SV
46546-513-0	CIRCUIT BOARD,PRINTED	1558	SV
46546-514-0	CIRCUIT BOARD,PRINTED	1138	SV
46546-514-0	CIRCUIT BOARD,PRINTED	1232	SV
46546-514-0	CIRCUIT BOARD,PRINTED	1197	SV
46546-515-0	CIRCUIT BOARD,PRINTED	1077	SV
46546-515-0	CIRCUIT BOARD,PRINTED	1431	SV
46546-524-0	CIRCUIT BOARD,PRINTED	1279	SV
46546-524-0	CIRCUIT BOARD,PRINTED	1018	SV
46546-524-0	CIRCUIT BOARD,PRINTED	1070	SV
46546-524-0	CIRCUIT BOARD,PRINTED	1044	SV
4679C000	VALVE,TEMP CONTROL (SASSY)	214972-3	SV
4679C000	VALVE,TEMP CONTROL (SASSY)	A208115-3	SV
4727C000	SENSOR,ECS TEMP (SASSY)	276219-2	SV
4727C000	SENSOR,ECS TEMP (SASSY)	819746-3	SV
4727C000	SENSOR,ECS TEMP (SASSY)	647038-4	SV
473597-4-07	SMOKE DETECTOR	5214	SV
473597-4-07	SMOKE DETECTOR	10636	SV
473925	ELECTRONIC CONTROL UNIT	5377	SV
473925	ELECTRONIC CONTROL UNIT	5729	SV
473996-1	EXTINGUISHER CARGO HRD (MASSY)	10111EL HAZMAT	SV
473996-1	EXTINGUISHER CARGO HRD (MASSY)	10052EL HAZMAT	SV
473996-1	EXTINGUISHER CARGO HRD (MASSY)	10108EL HAZMAT	SV
473996-1	EXTINGUISHER CARGO HRD (MASSY)	10164EL HAZMAT	SV
473996-1	EXTINGUISHER CARGO HRD (MASSY)	10039EL HAZMAT	SV
4747C000	SENSOR,FLOW CONTROL VALVE	462271-15	SV
4747C000	SENSOR,FLOW CONTROL VALVE	A961795-5	SV
4754C000	EXCHANGER,HEAT,PRIMARY (SASSY)	A437418-1	SV
4754C000	EXCHANGER,HEAT,PRIMARY (SASSY)	B660836-1	SV
4754C000	EXCHANGER,HEAT,PRIMARY (SASSY)	514743-1	SV
48351-101-0	UNIT,AUDIBLE WARNING,WPG	1021	SV
48351-101-0	UNIT,AUDIBLE WARNING,WPG	1205	SV
48351-101-0	UNIT,AUDIBLE WARNING,WPG	1119	SV
48351-101-0	UNIT,AUDIBLE WARNING,WPG	1173	SV
48351-311-0	PANEL,CENTRAL WARNING	021	SV
48351-326-0	CENTRAL WARNING PANEL	011	SV
4888C000	PUMP	33648-1	SV
4950632	VALVE	0040	SV
5001	DETECTOR,FUSE FAILURE	264	SV
5001	DETECTOR,FUSE FAILURE	261	SV
50-0124-3	LAMP ASSY,LANDING/TAXI	0227	SV
50-0124-3	LAMP ASSY,LANDING/TAXI	0323	SV

50-0124-3	LAMP ASSY,LANDING/TAXI	0082	SV
50-0124-3	LAMP ASSY,LANDING/TAXI	0951	SV
50-0124-3	LAMP ASSY,LANDING/TAXI	0083	SV
501-1-13775-008	MOTOR, DC STARTER	RG0159	SV
501-1-13775-008	MOTOR, DC STARTER	TE1038	SV
501-1-13775-008	MOTOR, DC STARTER	TE0904	SV
501-1-13775-008	MOTOR, DC STARTER	TE0847	SV
501-1-13775-008	MOTOR, DC STARTER	TE0695	SV
501-1-13775-008	MOTOR, DC STARTER	TE2612	SV
501-1-13775-008	MOTOR, DC STARTER	TE1363	SV
501-1-13775-008	MOTOR, DC STARTER	TE0990	SV
503/1/06680/003	GENERATOR ONLY,AC	TE0711	SV
503/1/06680/003	GENERATOR ONLY,AC	TA638X	SV
503/1/06680/003	GENERATOR ONLY,AC	TE1784A	SV
50652-1	TRANSMITTER,HYD PRESSURE	S878AR	SV
50652-1	TRANSMITTER,HYD PRESSURE	S868AR	SV
50652-1	TRANSMITTER,HYD PRESSURE	461	SV
50652-1	TRANSMITTER,HYD PRESSURE	48	SV
50652-1	TRANSMITTER,HYD PRESSURE	636A	SV
50652-1	TRANSMITTER,HYD PRESSURE	843A	SV
509/1/02530/001	RECTIFIER/TRANSFORMER	TE0609	SV
509/1/02530/001	RECTIFIER/TRANSFORMER	TE0610	SV
509/1/02530/001	RECTIFIER/TRANSFORMER	TE0581	SV
509/1/02530/001	RECTIFIER/TRANSFORMER	TE0764	SV
509/1/02530/001	RECTIFIER/TRANSFORMER	TE0541	SV
515CUF2	SELECTOR,ALTITUDE	267	SV
515CUF-2	SELECTOR,ALTITUDE	126	SV
516CUF1	SELECTOR,NAVIGATION	204	SV
516CUF1	SELECTOR,NAVIGATION	174	SV
516CUF1	SELECTOR,NAVIGATION	288	SV
516CUF1	SELECTOR,NAVIGATION	117	SV
516CUF-1	SELECTOR,NAVIGATION	341	SV
519892-6-2	MOTOR,APU STARTER 146(SASSY)	55-2377	SV
519892-6-2	MOTOR,APU STARTER 146(SASSY)	55-2372C	SV
519892-6-2	MOTOR,APU STARTER 146(SASSY)	18-5734	SV
519892-6-2	MOTOR,APU STARTER 146(SASSY)	47-5576	SV
519892-6-2	MOTOR,APU STARTER 146(SASSY)	75-5227	SV
519892-6-2	MOTOR,APU STARTER 146(SASSY)	71-1406C	SV
519892-6-2	MOTOR,APU STARTER 146(SASSY)	16-5306	SV
519892-6-2	MOTOR,APU STARTER 146(SASSY)	16-2795	SV
519892-6-2	MOTOR,APU STARTER 146(SASSY)	45-5164	SV
519892-6-2	MOTOR,APU STARTER 146(SASSY)	20-1011C	SV
519892-6-2	MOTOR,APU STARTER 146(SASSY)	46-2918	SV
519892-6-2	MOTOR,APU STARTER 146(SASSY)	125-2722	SV
520833	PUMP,AC HYDRAULIC	F9023444	SV
5216-00-1	VALVE,ICE/RAIN P.REDUC (SASSY)	0129	SV
5216-00-1	VALVE,ICE/RAIN P.REDUC (SASSY)	0014	SV
5216-00-1	VALVE,ICE/RAIN P.REDUC (SASSY)	0133	SV
5216-00-1	VALVE,ICE/RAIN P.REDUC (SASSY)	0127	SV
5216-00-1	VALVE,ICE/RAIN P.REDUC (SASSY)	0128	SV
5216-00-1	VALVE,ICE/RAIN P.REDUC (SASSY)	0130	SV
5216-00-1	VALVE,ICE/RAIN P.REDUC (SASSY)	0131	SV

5216-00-1	VALVE,ICE/RAIN P.REDUC (SASSY)	0106	SV
5216-00-1	VALVE,ICE/RAIN P.REDUC (SASSY)	0016	SV
522-1936-049	INDICATOR,SLAVE COMPASS	3483	SV
522247	INDICATOR,ENGINE VIBRA.	12851186	SV
522247	INDICATOR,ENGINE VIBRA.	05861202	SV
522-2996-011	RECEIVER,MARKER BEACON	16106	SV
522-2996-011	RECEIVER,MARKER BEACON	16186	SV
522-2996-011	RECEIVER,MARKER BEACON	16936	SV
522-2996-011	RECEIVER,MARKER BEACON	17162	SV
522-3176-005	CORECTOR,ADF QE	15583	SV
5234-02	CIRCUIT BOARD,PRINTED	1043	SV
5234-02	CIRCUIT BOARD,PRINTED	508	SV
53183-107-03	SWITCH,BLEED AIR OVTEMP	NA	SV
53183-107-03	SWITCH,BLEED AIR OVTEMP	NA	SV
53183-109	SWITCH,LOW TEMPERATURE	HSJ/8410064	SV
53183-109	SWITCH,LOW TEMPERATURE	0046P	SV
53183-109	SWITCH,LOW TEMPERATURE	R121	SV
53183-109	SWITCH,LOW TEMPERATURE	J0231	SV
568/1/25665/001	PUMP,F.BOOST,ELECTRIC	551	SV
568/1/25665/001	PUMP,F.BOOST,ELECTRIC	566	SV
568/1/25665/001	PUMP,F.BOOST,ELECTRIC	480	SV
568/1/25665/001	PUMP,F.BOOST,ELECTRIC	809	SV
568/1/25666/001	CANISTER	694	SV
568/1/25666/001	CANISTER	895	SV
568-1-25663-001	PUMP,FUEL,HYDR.DRIVEN	601	SV
568-1-25663-001	PUMP,FUEL,HYDR.DRIVEN	275	SV
57333-012	FIRE EXT,ENG/APU (SASSY)	CN5535M Hazmat	SV
57333-012	FIRE EXT,ENG/APU (SASSY)	CN2K12M HAZMAT	SV
57333-012	FIRE EXT,ENG/APU (SASSY)	CK6772M HAZMAT	SV
57333-012	FIRE EXT,ENG/APU (SASSY)	CN9237M HAZMAT	SV
57333-012	FIRE EXT,ENG/APU (SASSY)	CV607M HAZMAT	SV
57333-012	FIRE EXT,ENG/APU (SASSY)	CL1032M HAZMAT	SV
57333-012	FIRE EXT,ENG/APU (SASSY)	CK6767M HAZMAT	SV
57333-012	FIRE EXT,ENG/APU (SASSY)	CP4731M HAZMAT	SV
57333-012	FIRE EXT,ENG/APU (SASSY)	CM4261M HAZMAT	SV
1/3/6001	DISPLAY SWITCHING UNIT	651	SV
1/3/6001	DISPLAY SWITCHING UNIT	650	SV
1/3/6001	DISPLAY SWITCHING UNIT	645	SV
60-2388-101	DRIVE PACK,TAIL STROBE	1167	SV
60-2388-101	DRIVE PACK,TAIL STROBE	1050	SV
60-2388-101	DRIVE PACK,TAIL STROBE	521	SV
60-2388-101	DRIVE PACK,TAIL STROBE	1039	SV
60-3550-1	POWER SUPPLY,EMERG LIGHTS	800	SV
60-3550-1	POWER SUPPLY,EMERG LIGHTS	229	SV
60-3550-1	POWER SUPPLY,EMERG LIGHTS	1029	SV
60-3550-1	POWER SUPPLY,EMERG LIGHTS	2050RE	SV
60-3550-1	POWER SUPPLY,EMERG LIGHTS	617	SV
60-3550-1	POWER SUPPLY,EMERG LIGHTS	279	SV
60-3550-1	POWER SUPPLY,EMERG LIGHTS	114	SV
60-3550-1	POWER SUPPLY,EMERG LIGHTS	1003	SV
60-3550-1	POWER SUPPLY,EMERG LIGHTS	977	SV
60-3550-1	POWER SUPPLY,EMERG LIGHTS	1210	SV

60-3550-1	POWER SUPPLY,EMERG LIGHTS	507	SV
60-3550-1	POWER SUPPLY,EMERG LIGHTS	1058	SV
60-3550-1	POWER SUPPLY,EMERG LIGHTS	858	SV
60-3550-1	POWER SUPPLY,EMERG LIGHTS	226	SV
60-3550-1	POWER SUPPLY,EMERG LIGHTS	1036	SV
622-1181-001	TRANSCEIVER,VHF COMM	11470	SV
622-1181-001	TRANSCEIVER,VHF COMM	14438	SV
622-1181-001	TRANSCEIVER,VHF COMM	8196	SV
622-2224-001	TRANSPONDER MODE C	6028	SV
622-2224-001	TRANSPONDER MODE C	6413	SV
622-2224-001	TRANSPONDER MODE C	6488	SV
622-2921-002	RECEIVER,DME	11664	SV
622-2921-002	RECEIVER,DME	10522	SV
6222S-50AM1	ACCELEROMETER,ENGINE (SASSY)	CJ72	SV
6222S-50AM1	ACCELEROMETER,ENGINE (SASSY)	AR83	SV
6222S-50AM1	ACCELEROMETER,ENGINE (SASSY)	AG24	SV
6222S-50AM1	ACCELEROMETER,ENGINE (SASSY)	BF76	SV
6222S-50AM1	ACCELEROMETER,ENGINE (SASSY)	AG62	SV
6222S-50AM1	ACCELEROMETER,ENGINE (SASSY)	AR32	SV
6222S-50AM1	ACCELEROMETER,ENGINE (SASSY)	AG18	SV
6222S-50AM1	ACCELEROMETER,ENGINE (SASSY)	BE92	SV
6222S-50AM1	ACCELEROMETER,ENGINE (SASSY)	AG65	SV
6222S-50AM1	ACCELEROMETER,ENGINE (SASSY)	CM28	SV
6222S-50AM1	ACCELEROMETER,ENGINE (SASSY)	BG13	SV
6222S-50AM1	ACCELEROMETER,ENGINE (SASSY)	14006	SV
622-3890-002	TRANSCEIVER,RADIO ALT.	2450	SV
622-3890-002	TRANSCEIVER,RADIO ALT.	5134	SV
622-3890-002	TRANSCEIVER,RADIO ALT.	5018	SV
622-4096-002	AMPLIFIER,PSSNGR ADDRESS	3171	SV
622-4096-002	AMPLIFIER,PSSNGR ADDRESS	4026	SV
622-4096-002	AMPLIFIER,PSSNGR ADDRESS	1780	SV
622-4096-002	AMPLIFIER,PSSNGR ADDRESS	4723	SV
622-4096-002	AMPLIFIER,PSSNGR ADDRESS	5393	SV
622-4160-015	INDICATOR,RADIO ALTITUDE	4006	SV
622-4160-015	INDICATOR,RADIO ALTITUDE	3428	SV
622-4160-015	INDICATOR,RADIO ALTITUDE	3843	SV
622-4160-015	INDICATOR,RADIO ALTITUDE	4409	SV
622-5128-203	INDICATOR,RADAR COLLINS	1434	SV
622-5132-102	TRANSCVR,RADR, COLLINS	87	SV
622-5132-107	TRANSCVR,RADR, COLLINS	4887	SV
622-6514-203	INDICATOR,RADAR COLLINS	2054	SV
622-7878-201	TRANSPONDER MODE S	5502	SV
622-7878-201	TRANSPONDER MODE S	2925	SV
622-7878-201	TRANSPONDER MODE S	5496	SV
622-7878-201	TRANSPONDER MODE S	4637	SV
622-8971-020	PROCESSOR- TCAS	10085	SV
622-8971-020	PROCESSOR- TCAS	330	SV
622-9353-211	VSI/RA/TA	790	SV
622-9353-211	VSI/RA/TA	719	SV
622-9353-211	VSI/RA/TA	700	SV
622-9353-211	VSI/RA/TA	855	SV
622-9353-213	VSI/RA/TA	402	SV

622-9353-215	VSI/RA/TA	745	SV
622-9353-215	VSI/RA/TA	426	SV
6435-003-00	SWITCH,SLCTR-LNDNG GEAR	4-84	SV
6435-003-00	SWITCH,SLCTR-LNDNG GEAR	34-88	SV
6435-003-00	SWITCH,SLCTR-LNDNG GEAR	19-87	SV
6508-5	COMPUTER WINDSHEAR	127	REP
6508-5	COMPUTER WINDSHEAR	159	REP
6508-5	COMPUTER WINDSHEAR	165	REP
658SUE5	MONITOR,COMPUTER	1264	SV
658SUE5	MONITOR,COMPUTER	1129	SV
658SUE6	MONITOR COMPUTER	1365	REP
6610M43	CONDITIONER,SIGNAL	088449	SV
6610M43	CONDITIONER,SIGNAL	028748	SV
671102100	DIMMER,FLIGHT DECK	162-88	SV
671102100	DIMMER,FLIGHT DECK	3-83-87	SV
671102200	DIMMER,INSTRUMENT PANEL	014-99	SV
671102200	DIMMER,INSTRUMENT PANEL	84-83-86	REP
671102200	DIMMER,INSTRUMENT PANEL	179-85	REP
671102200	DIMMER,INSTRUMENT PANEL	223-87	REP
671102200	DIMMER,INSTRUMENT PANEL	177-87-90R	INS
671102200	DIMMER,INSTRUMENT PANEL	64-88	REP
671102300	DIMMER,OVERHEAD PANEL	85-85-90R	REP
671102300	DIMMER,OVERHEAD PANEL	229-84	REP
676001014	JACK,SCREW	DRG4478/89	SV
676101005	CONTROL,FLAP (P.C.U.)	DRG/2154/89	SV
676101005	CONTROL,FLAP (P.C.U.)	DRG/8713/85	SV
676101005	CONTROL,FLAP (P.C.U.)	DRG/846/86	SV
676101230	GENERATOR,FLAP CONTROL	PG76	SV
676101262	GENERATOR,FLAP CONTROL	PG150	SV
676101264	RESOLVER	0583G0946	SV
676101264	RESOLVER	1182G1076	SV
676201010	LIMITER,TORQUE	DRG/7238/88	SV
676201010	LIMITER,TORQUE	DRG/720/86	SV
676201011	LIMITER,TORQUE	DRG4191-83	SV
676201011	LIMITER,TORQUE	DRG378-83	SV
676201012	LIMITER,TORQUE	DRG/5987/87	SV
676301003	FLAP POS/SIG ASSY LH (MASSY)	DRG/5272/84	SV
676301003	FLAP POS/SIG ASSY LH (MASSY)	DRG1166/88	SV
676301004	FLAP POS/SIG ASSY RH (MASSY)	DRG1831-89	SV
676301226	RESOLVER (SASSY)	1284D191	INS
676301226	RESOLVER (SASSY)	887D84	INS
676301231	RESOLVER (SASSY)	1182F1177	REP
676501001	CONTROL UNIT,PITCH TRIM	DAW197-01	SV
676601004	UNIT,BRAKE,FLAP ASYMMETRY	DRG/1072	SV
676701201	SHAFT	DRG/4882/86	SV
676701201	SHAFT	DRG/1620/86	SV
676701201	SHAFT	DRG/4850/88	SV
676701202	SHAFT	DRG371	SV
676701202	SHAFT	DRG/3079/84	SV
676701211	JOINT,UNIVERSAL-FLAP SYS	MUJ408101	SV
676701211	JOINT,UNIVERSAL-FLAP SYS	MUJ374100	SV
676701211	JOINT,UNIVERSAL-FLAP SYS	DRG/8090/87	SV

676701211	JOINT,UNIVERSAL-FLAP SYS	DRG/808	SV
676801007	CONTROLLER,TRAILING FLAPS	UEL/DRG/1235/88	SV
676801007	CONTROLLER,TRAILING FLAPS	UEL/DRG/1079/84	SV
676801007	CONTROLLER,TRAILING FLAPS	DRG/1271/88	SV
676801007	CONTROLLER,TRAILING FLAPS	UEL/DRG/1116/85	SV
676901002	UNIT,PILOT COMMAND SIGNAL	17-86	SV
692545-1	VALVE,SOLENOID-100APU (SASSY)	42598	SV
692545-1	VALVE,SOLENOID-100APU (SASSY)	20857	SV
700/1/22490/420	GENERATOR CONTROL UNIT	TE0799	SV
700/1/22490/420	GENERATOR CONTROL UNIT	TE0961	SV
700/1/22490/420	GENERATOR CONTROL UNIT	TE0174	SV
700/1/22490/420	GENERATOR CONTROL UNIT	TJ870	SV
700013323	CENTER SUB ASSY,RH	NA	SV
700013323	CENTER SUB ASSY,RH	NA	SV
700013324	CONDUIT,LH	203M016-62-0010	SV
700013324	CONDUIT,LH	203M016-19C10	SV
700013324	CONDUIT,LH	203M016-19-C10	SV
700014223	CENTER SUB ASSY,RH	NA	SV
700014223	CENTER SUB ASSY,RH	NA	SV
70-AA6-511	FAN,HYDRAULIC OIL COOLING	430862S	SV
70AA6521	FAN,HYDRAULIC OIL COOLING	443992S	SV
70AA6521	FAN,HYDRAULIC OIL COOLING	443997S	SV
70AA6521	FAN,HYDRAULIC OIL COOLING	442970S	SV
70AA6521	FAN,HYDRAULIC OIL COOLING	442978S	SV
70AA6521	FAN,HYDRAULIC OIL COOLING	443993S	SV
70-AA6-521	FAN,HYDRAULIC OIL COOLING	441315S	SV
70-AA6-521	FAN,HYDRAULIC OIL COOLING	418705	SV
70-AA6-521	FAN,HYDRAULIC OIL COOLING	420379	SV
70-AA6-521	FAN,HYDRAULIC OIL COOLING	442977S	SV
70-AA6-521	FAN,HYDRAULIC OIL COOLING	421281	SV
70-AA6-521	FAN,HYDRAULIC OIL COOLING	462450S	SV
70-AA6-521	FAN,HYDRAULIC OIL COOLING	421278	SV
70-AA6-521	FAN,HYDRAULIC OIL COOLING	423432	SV
710-13300-2246	CONTROLLER,CABIN ALTITUDE	1870	SV
710-13300-2246	CONTROLLER,CABIN ALTITUDE	1922	SV
710-13300-2246	CONTROLLER,CABIN ALTITUDE	1724	SV
710-13300-2246	CONTROLLER,CABIN ALTITUDE	1544	SV
715745	VALVE,IN-LINE RELIEF	F5822538	SV
715745	VALVE,IN-LINE RELIEF	F4841344	SV
715745	VALVE,IN-LINE RELIEF	F1834305	SV
715745	VALVE,IN-LINE RELIEF	F7847600	SV
715750	PUMP,DC HYDRAULIC	F3817459	SV
715750	PUMP,DC HYDRAULIC	F4820371	SV
715776	PUMP,AC HYDRAULIC	F8818662	SV
715874	GENERATOR ASY,STANDBY	143/46	SV
715874A	GENERATOR ASY,STANDBY	0213/50	SV
716988	PUMP,HYDRAULIC,ENG DRIVEN	F4830769	SV
716988	PUMP,HYDRAULIC,ENG DRIVEN	F5811706	SV
716988	PUMP,HYDRAULIC,ENG DRIVEN	F1834349	SV
716988	PUMP,HYDRAULIC,ENG DRIVEN	78839884	SV
720-15900-906	ALTIMETER,CABIN	1597	SV
72-130003-001	DETECTOR, SMOKE	6783	SV

72-130003-001	DETECTOR, SMOKE	9854	SV
72-130003-001	DETECTOR, SMOKE	6790	SV
72-130003-001	DETECTOR, SMOKE	9698	SV
72-130003-001	DETECTOR, SMOKE	8557-0	SV
7216-1000-1	RECEIVER,DME	286	SV
7216-1000-1	RECEIVER,DME	038	SV
728403B	GEARBOX,APU GENERATOR	0128	SV
728403C	GEARBOX,APU GENERATOR	0447	SV
728471	CSD,PART OF IDG	0266	SV
728471B	CSD,PART OF IDG	0198	SV
728471C	CSD,PART OF IDG	0374	SV
728471C	CSD,PART OF IDG	0242	SV
728471C	CSD,PART OF IDG	0467	SV
740SUE8-6	COMPUTER, A/P 100-200	C1067	SV
740SUE8-6	COMPUTER, A/P 100-200	C1126	SV
740SUE9-7	COMPUTER AUTO PILOT 300	1255	SV
740SUE9-7	COMPUTER AUTO PILOT 300	1281	SV
740SUE9-7	COMPUTER AUTO PILOT 300	1194	SV
741SUE3	COMPUTER,YAW DAMPER	1350	SV
741SUE3	COMPUTER,YAW DAMPER	1405	SV
741SUE3	COMPUTER,YAW DAMPER	1243	SV
747SUE/2	GEARING PAD,YAW COMPUTER	6483	SV
747SUE/2	GEARING PAD,YAW COMPUTER	6482	SV
747SUE/2	GEARING PAD,YAW COMPUTER	8015	SV
747SUE2	GEARING PAD,YAW COMPUTER	8480	SV
747SUE5	YAW COMPUTOR PAD	8300	SV
772-5005-005	ADI,FLIGHT DIR IND.	2J1457	SV
772-5005-005	ADI,FLIGHT DIR IND.	9A3024	SV
777-1397-010	HSI	6K6335	SV
777-1397-010	HSI	876547	SV
777-1492-004	RECEIVER,ADF	15923	SV
777-1492-004	RECEIVER,ADF	16518	SV
777-1492-004	RECEIVER,ADF	14104	SV
777-1492-004	RECEIVER,ADF	14968	SV
7808-1000-1	TACAN DME RANGE UNIT	22077	SV
7808-1000-1	TACAN DME RANGE UNIT	22017	SV
7808-1000-1	TACAN DME RANGE UNIT	22348	SV
7808-1000-1	TACAN DME RANGE UNIT	22573	SV
7808-1000-1	TACAN DME RANGE UNIT	21752	SV
7808-1000-1	TACAN DME RANGE UNIT	22025	SV
7808-1000-1	TACAN DME RANGE UNIT	21590	SV
7808-1000-1	TACAN DME RANGE UNIT	21907	SV
7913003/K	VALVE	FRTR110/D	SV
7913003/K	VALVE	FRTR451/F	SV
7913003/K	VALVE	FRTR275/P	SV
7913003/K	VALVE	FRTR177/E	SV
7940005/H	VALVE,OVERFLOW	FRTR112/M	SV
7940005H	VALVE,OVERFLOW	FRTR123/V	SV
7940023F	VALVE,WASTE/H2O CHARGING	FRTR107/L	SV
7940023F	VALVE,WASTE/H2O CHARGING	FR002BD	SV
7940066F	VALVE,WASTE/H2O CHARGING	FR005BN	SV
801CUF-3	SELECTOR,AUTOPILOT CNTRL	141	SV

805D0602-00	DME/TACAN TRANSCEIVER	170	SV
8-060-02	CIRCUIT BOARD,PRINTED	78808	SV
8-060-02	CIRCUIT BOARD,PRINTED	130389	SV
8-060-02	CIRCUIT BOARD,PRINTED	91157	SV
8-060-02	CIRCUIT BOARD,PRINTED	129806	SV
8-060-02	CIRCUIT BOARD,PRINTED	108461	SV
8-060-02	CIRCUIT BOARD,PRINTED	91235	SV
8-060-02	CIRCUIT BOARD,PRINTED	109762	SV
8-060-02	CIRCUIT BOARD,PRINTED	88090	SV
8-060-02	CIRCUIT BOARD,PRINTED	119496	SV
8-060-02	CIRCUIT BOARD,PRINTED	88108	SV
8-060-02	CIRCUIT BOARD,PRINTED	100604	SV
8-060-02	CIRCUIT BOARD,PRINTED	90033	SV
811B	CLOCK, DIGITAL	22999	SV
811B	CLOCK, DIGITAL	18814	SV
811B	CLOCK, DIGITAL	20715	SV
811B	CLOCK, DIGITAL	21137	SV
811B	CLOCK, DIGITAL	20995	SV
811B	CLOCK, DIGITAL	26279	SV
811B	CLOCK, DIGITAL	21400	SV
811B	CLOCK, DIGITAL	21808	SV
811B	CLOCK, DIGITAL	25204	SV
811B	CLOCK, DIGITAL	20340	SV
811B	CLOCK, DIGITAL	25207	SV
811B	CLOCK, DIGITAL	26281	SV
811B	CLOCK, DIGITAL	22877	SV
811B	CLOCK, DIGITAL	18989	SV
811B	CLOCK, DIGITAL	21150	SV
811B	CLOCK, DIGITAL	19187	SV
811B	CLOCK, DIGITAL	19191	SV
811B24	CLOCK, DIGITAL	23786	SV
811B24	CLOCK, DIGITAL	31369	SV
823CUF2	SELECTOR,MODE	177	SV
823CUF-2	SELECTOR,MODE	110	SV
823CUF-2	SELECTOR,MODE	630	SV
83-000-004	DAMPER	83-460	SV
83-000-004	DAMPER	83-018	SV
83-000-004	DAMPER	83-171	SV
83273-1	SWITCH,HYD OVERTEMP	1283TW	SV
83273-1	SWITCH,HYD OVERTEMP	1259TW	SV
83305	SWITCH,TEMPERATURE	1297	SV
853JE	PITOTHEAD,AUXILARY	10313	SV
853JE	PITOTHEAD,AUXILARY	10316	SV
853JR	PITOTHEAD,PILOT	7666E	SV
853JR	PITOTHEAD,PILOT	1374	SV
853JS	PITOTHEAD,COPILOT	11665	SV
853JS	PITOTHEAD,COPILOT	11570	SV
861000013	POTENTIOMETER,P.TRIM	30784	SV
861000013	POTENTIOMETER,P.TRIM	17-85	SV
88000-4102	MECHANICAL CLOCK	825998	SV
9-127-48	TRANSMITTER,FUEL FLOW, (SASSY)	2861A	SV
9-127-48	TRANSMITTER,FUEL FLOW, (SASSY)	2916A	SV

9-127-48	TRANSMITTER,FUEL FLOW, (SASSY)	3656A	SV
9-127-48	TRANSMITTER,FUEL FLOW, (SASSY)	3770A	SV
9-127-48	TRANSMITTER,FUEL FLOW, (SASSY)	3857A	SV
9-127-48	TRANSMITTER,FUEL FLOW, (SASSY)	3877A	SV
9-127-48	TRANSMITTER,FUEL FLOW, (SASSY)	59	INS
9-127-48	TRANSMITTER,FUEL FLOW, (SASSY)	4425	INS
9201000/226	TRANSMITTER,OIL QUANTI (SASSY)	FRTR1017AX	SV
9201000/226	TRANSMITTER,OIL QUANTI (SASSY)	FRTR300-AE	SV
9201000/243	TRANSMITTER,HYD QTY	FRTR238/V	SV
9201000-226	TRANSMITTER,OIL QUANTI (SASSY)	FRTR089-N	SV
9201000-226	TRANSMITTER,OIL QUANTI (SASSY)	FRTR986AW	SV
9201000-226	TRANSMITTER,OIL QUANTI (SASSY)	FRTR022-AA	INS
9201000-226	TRANSMITTER,OIL QUANTI (SASSY)	FRTR962AW	SV
9201000-226	TRANSMITTER,OIL QUANTI (SASSY)	FRTR021-AA	SV
9201000-243	TRANSMITTER,HYD QTY	FRTR146/R	SV
9-328-20	INDICATOR,FUEL FLOW	1007	SV
9-328-20	INDICATOR,FUEL FLOW	1104	SV
9-328-20	INDICATOR,FUEL FLOW	1102	SV
9-328-20	INDICATOR,FUEL FLOW	1130	SV
9-328-20	INDICATOR,FUEL FLOW	1487	SV
9-328-20	INDICATOR,FUEL FLOW	1761	SV
9-328-20	INDICATOR,FUEL FLOW	1892	SV
9-328-20	INDICATOR,FUEL FLOW	5	SV
965-0412-002	COMP, BAROMETRIC ALT RATE	1172	SV
965-0476-088	COMPUTER,GPWS	4079	SV
965-0476-088	COMPUTER,GPWS	4143	SV
9750-0640	BATTERY, LEAD ACID	2039	SV
9750-0640	BATTERY, LEAD ACID	RK7562	SV
9750-0640	BATTERY, LEAD ACID	RH4609	SV
9750-0640	BATTERY, LEAD ACID	RK3497	SV
9750-0640	BATTERY, LEAD ACID	RH8404	SV
9750-0750	BATTERY, LEAD ACID	RK3496	SV
9750-0750	BATTERY, LEAD ACID	RK7041	SV
9750-0750	BATTERY, LEAD ACID	K8879	SV
9750-0750	BATTERY, LEAD ACID	K8872	SV
978668-3-1	VALVE,APU SURGE SHUTOF (SASSY)	P-1345	SV
978668-3-1	VALVE,APU SURGE SHUTOF (SASSY)	2885	SV
9BG401-572-00	LENSE ASSY	1425	SV
9BG401-572-00	LENSE ASSY	3693	SV
A30160	TANK,FWD/REAR TOILET	BAH3047-82	SV
A30200	TANK,FWD/REAR TOILET	WHS/BA/HAT/0135	SV
A30200	TANK,FWD/REAR TOILET	BAHAT227	SV
A30200	TANK,FWD/REAR TOILET	BAHAT17587	SV
A30200	TANK,FWD/REAR TOILET	BAHAT108486	SV
A-703CSM	CONTACTOR,ENGINE START	CH-30123	SV
A-703CSM	CONTACTOR,ENGINE START	CE77168	SV
A-703CSM	CONTACTOR,ENGINE START	CG-79991	SV
A-703CSM	CONTACTOR,ENGINE START	CG-91082	SV
A-703CSM	CONTACTOR,ENGINE START	CP-31399	SV
A-703CSM	CONTACTOR,ENGINE START	CG-97496	SV
A-703CSM	CONTACTOR,ENGINE START	CG-66180	SV
A-703CSM	CONTACTOR,ENGINE START	CG-66884	SV

A-703CSM	CONTACTOR,ENGINE START	CG-66160	SV
A-703CSM	CONTACTOR,ENGINE START	CH-28871	SV
A-703CSM	CONTACTOR,ENGINE START	CH-53644	SV
A-703CSM	CONTACTOR,ENGINE START	CG-81088	SV
A-703CSM	CONTACTOR,ENGINE START	CG-93166	SV
A-703CSM	CONTACTOR,ENGINE START	CJ-86803	SV
A-703CSM	CONTRACTOR, ENGINE START	CG-66159	SV
A-712RS	CONTACTOR,DC	CJ-17410	SV
A-712RS	CONTACTOR,DC	CG-19833	SV
A-712RS	CONTACTOR,DC	CH-21235	SV
A-848MLS	CONTACTOR,APU START	CH-91920	SV
A-957CSD	CONTACTOR,DC	CE-57663	INS
A-957CSD	CONTACTOR,DC	CG-81484	MOD
A-957CSD	CONTACTOR,DC	CH-91893	REP
A-957CSD	CONTACTOR,DC	CM-51598	REP
AA15504-11-002	BOX,AUDIO CONTROL	784877	SV
AA15504-11-005	BOX,AUDIO CONTROL	774511	SV
AA15504-11-005	BOX,AUDIO CONTROL	788773	SV
AA15504-11-005	BOX,AUDIO CONTROL	797697	SV
AA15505-1	UNIT,MICROPHONE	788923	SV
AC65180	VALVE,PRESSURE REGULATOR	LF541	SV
AC65180	VALVE,PRESSURE REGULATOR	GU329	SV
AC65180	VALVE,PRESSURE REGULATOR	LH054	SV
AC65184	VALVE,PRESSURE REGULATOR	HB368	SV
AC65184	VALVE,PRESSURE REGULATOR	EE413	SV
AC65184	VALVE,PRESSURE REGULATOR	GV196	SV
AC65716	VALVE,SOLENOID	GS237	SV
AC65716	VALVE,SOLENOID	DD218	SV
AC65716	VALVE,SOLENOID	DV287	SV
AC65716	VALVE,SOLENOID	LB075	SV
AC65716	VALVE,SOLENOID	ED241	SV
AC65716	VALVE,SOLENOID	HJ232	SV
AC65716	VALVE,SOLENOID	DD213	SV
AC65716	VALVE,SOLENOID	HB327	SV
AC65716	VALVE,SOLENOID	DE578	SV
AC65716	VALVE,SOLENOID	GW397	SV
AC65716	VALVE,SOLENOID	DV286	SV
AC65716	VALVE,SOLENOID	ED237	SV
AC65718	SOLENOID VALVE	FE383	SV
AC65718	SOLENOID VALVE	KX599	SV
AC65718	SOLENOID VALVE	HX093	SV
AC65718	SOLENOID VALVE	JB135	SV
AC65718	SOLENOID VALVE	MN428	SV
AC67070	INDICATOR,BRAKE TEMP	LV747	SV
AC67070	INDICATOR,BRAKE TEMP	H556	SV
AC67070	INDICATOR,BRAKE TEMP	MS014	SV
AC67650	VALVE,ANTI-SKID	LN184	SV
AC67650	VALVE,ANTI-SKID	HG258	SV
AC67650	VALVE,ANTI-SKID	KW546	SV
AC67650	VALVE,ANTI-SKID	KW557	SV
AC67650	VALVE,ANTI-SKID	HG260	SV
AC67650	VALVE,ANTI-SKID	NB202	SV

AC67650	VALVE,ANTI-SKID	MV381	SV
AC67650	VALVE,ANTI-SKID	MX289	SV
AC67650	VALVE,ANTI-SKID	MJ160	SV
AC67726	VALVE,R/H DUAL GAIN	HK272	SV
AC67726	VALVE,R/H DUAL GAIN	RA063	SV
AC67726	VALVE,R/H DUAL GAIN	KH173	SV
AC67726	VALVE,R/H DUAL GAIN	KV020	SV
AC67728	VALVE,L/H DUAL GAIN	GR067	SV
AC67728	VALVE,L/H DUAL GAIN	HC405	SV
AC67728	VALVE,L/H DUAL GAIN	69067	SV
AC67728	VALVE,L/H DUAL GAIN	FD387	SV
AC67764	VALVE,PRESSURE REDUCING	FY277	SV
AC67764	VALVE,PRESSURE REDUCING	HD269	SV
AC69076	DAMPER,FWD PAX/SERV DOOR	EEP193	SV
AC69076	DAMPER,FWD PAX/SERV DOOR	EGQ026	SV
AC69076	DAMPER,FWD PAX/SERV DOOR	EHB044	SV
AC69076	DAMPER,FWD PAX/SERV DOOR	KM718	SV
ACA1316	ACM28076,STALL IDENT	GV548	SV
ACA1316	ACM28076,STALL IDENT	G4066	SV
ACM28076	VALVE,WHEEL SPEED XDUCER	DX414	SV
ACM28076	VALVE,WHEEL SPEED XDUCER	JQ189	SV
ACM28076	VALVE,WHEEL SPEED XDUCER	GE128	SV
ACM28076	VALVE,WHEEL SPEED XDUCER	MG237	SV
ACM28076	VALVE,WHEEL SPEED XDUCER	LW120	SV
ACM28076	VALVE,WHEEL SPEED XDUCER	HJ104	SV
ACM28076	VALVE,WHEEL SPEED XDUCER	JA171	SV
ACM28076	VALVE,WHEEL SPEED XDUCER	MJ266	SV
ACM28076	VALVE,WHEEL SPEED XDUCER	ED022	SV
ACM28238	COMPARATOR	DA138	SV
ACM28248	VALVE	JA162	SV
ACM29044	FUSE,HYDRAULIC-R/B	EJ278	SV
ACM29044	FUSE,HYDRAULIC-R/B	EJ274	SV
ACM29044	FUSE,HYDRAULIC-R/B	EJ275	SV
ACM29044	FUSE,HYDRAULIC-R/B	HF451	SV
ACM29044	FUSE,HYDRAULIC-R/B	EJ273	SV
ACM29044	FUSE,HYDRAULIC-R/B	EJ279	SV
ACM29044	FUSE,HYDRAULIC-R/B	EJ276	SV
ACM29044	FUSE,HYDRAULIC-R/B	GV578	SV
ACM29044	FUSE,HYDRAULIC-R/B	FX393	SV
ACM30506	FUSE,HYDRAULIC-RPLZS	LN039	SV
ACM30506	FUSE,HYDRAULIC-RPLZS	LM152	SV
ACM30506	FUSE,HYDRAULIC-RPLZS	UT090	SV
ACM30506	FUSE,HYDRAULIC-RPLZS	LM443	SV
ACM30506	FUSE,HYDRAULIC-RPLZS	LM446	SV
ACM30506	FUSE,HYDRAULIC-RPLZS	UU065	SV
ACM30506	FUSE,HYDRAULIC-RPLZS	LN044	SV
ACM30506	FUSE,HYDRAULIC-RPLZS	NN096	SV
ACM30506	FUSE,HYDRAULIC-RPLZS	LX218	SV
ACR/EM-1	MEGAPHONE	AW26	SV
ACR/EM-1A	MEGAPHONE	10009	SV
ACR/EM-1A	MEGAPHONE	12434	SV
ACR/EM-1A	MEGAPHONE	6043	SV

ACR/EM-1A	MEGAPHONE	AW-6	SV
AE20556	CONTROL BOX,ANTI-SKID	HC240	SV
AE20556	CONTROL BOX,ANTI-SKID	HS028	SV
AE20558	CONTROL BOX,ANTI-SKID	LD459	SV
AE20558	CONTROL BOX,ANTI-SKID	JH052	SV
AHA1349	WHEEL ASSY, 146 NOSE	FL053	SV
AHA1349	WHEEL ASSY, 146 NOSE		SV
AHA1349	WHEEL ASSY, 146 NOSE		SV
AHA1349	WHEEL ASSY, 146 NOSE		SV
AHA1349	WHEEL ASSY, 146 NOSE		SV
AHA1349	WHEEL ASSY, 146 NOSE		SV
AHA1349	WHEEL ASSY, 146 NOSE		SV
AHA1349	WHEEL ASSY, 146 NOSE		SV
AHA1349	WHEEL ASSY, 146 NOSE		SV
AHA1349	WHEEL ASSY, 146 NOSE		SV
AHA1455	BRAKE,#2 AND #4	HD083	SV
AHA1455	BRAKE,#2 AND #4	HA270	SV
AHA1489	WHEEL ASSY, 146 MAIN	MA122	SV
AHA1489	WHEEL ASSY, 146 MAIN		SV
AHA1489	WHEEL ASSY, 146 MAIN		SV
AHA1489	WHEEL ASSY, 146 MAIN		SV
AHA1489	WHEEL ASSY, 146 MAIN		SV
AHA1489	WHEEL ASSY, 146 MAIN		SV
AHA1489	WHEEL ASSY, 146 MAIN		SV
AHA1489	WHEEL ASSY, 146 MAIN		SV
AHA1489	WHEEL ASSY, 146 MAIN		SV
AHA1489	WHEEL ASSY, 146 MAIN		SV
AHA1489	WHEEL ASSY, 146 MAIN		SV
AHA1489	WHEEL ASSY, 146 MAIN		SV
AHA1489	WHEEL ASSY, 146 MAIN		SV
AHA1489	WHEEL ASSY, 146 MAIN		SV
AHA2331-2	BRAKE ASSY,CARBON 200-300 2/4	JR043 (HUB ONLY)	SV
AHA2331-2	BRAKE ASSY,CARBON 200-300 2/4	HQ006 (HUB ONLY)	SV
AHA2331-2	BRAKE ASSY,CARBON 200-300 2/4	KA037 (HUB ONLY)	SV
AHA2331-2	BRAKE ASSY,CARBON 200-300 2/4	MM111 (HUB ONLY)	SV
AHA2331-2	BRAKE ASSY,CARBON 200-300 2/4	LBO30 (HUB ONLY)	SV
AHA2332	BRAKE ASSY,CARBON 200-300 1/3	HE224 (HUB ONLY)	SV
AHA2332-2	BRAKE ASSY,CARBON 200-300 1/3	KY007 (HUB ONLY)	SV
AHA2332-2	BRAKE ASSY,CARBON 200-300 1/3	MG251 (HUB ONLY)	SV
AHA2332-2	BRAKE ASSY,CARBON 200-300 1/3	GN262 (HUB ONLY)	SV
AHM10419	SPACER CARBON HEATPACK	F109827H	SV
AHM10419	SPACER CARBON HEATPACK	F0415HX	SV
AHM10419	SPACER CARBON HEATPACK	R0429044-11	SV
AHM10419	SPACER CARBON HEATPACK	F113859H	SV
AHM10419	SPACER CARBON HEATPACK	F0388HX	SV
AHM10419	SPACER CARBON HEATPACK	F0524HX	SV
AHM10419	SPACER CARBON HEATPACK	F0410HX	SV
AHM10419	SPACER CARBON HEATPACK	F088112H	SV
AHM10419	SPACER CARBON HEATPACK	F111360H	SV
AHM10419	SPACER CARBON HEATPACK	F088108H	SV
AHM10419	SPACER CARBON HEATPACK	F056434K	SV
AHM10419	SPACER CARBON HEATPACK	R0429044-3	SV
AHM10419	SPACER CARBON HEATPACK	F111373H	SV

AHM10419	SPACER CARBON HEATPACK	F100397K	SV
AHM10419	SPACER CARBON HEATPACK	R0429044-10	SV
AHM10419	SPACER CARBON HEATPACK	F099574K	SV
AHO91308	CARBON HEAT PACK 200/300	AW344	SV
AHO91308	CARBON HEAT PACK 200/300	AW329	SV
AHO91308	CARBON HEAT PACK 200/300	AW321	SV
AHO91308	CARBON HEAT PACK 200/300	AW341	SV
AHO91308	CARBON HEAT PACK 200/300	AW343	SV
AHO91308	CARBON HEAT PACK 200/300	AW345	SV
AHO91308	CARBON HEAT PACK 200/300	N/A	SV
AIR119762	GUAGE, HYDRAULIC ACCUM.	34874A	SV
AIR87442-2	DAMPER, ELEVATOR	APB020109	SV
AIR87442-2	DAMPER, ELEVATOR	APB020176	SV
AIR91652/0	VALVE, SELECTOR MLG	APB983213	SV
AIR91652/0	VALVE, SELECTOR MLG	APB963517	SV
AIR91652/0	VALVE, SELECTOR MLG	LK9000927	SV
AIR91654/0	VALVE,NON RETURN	LK8507968	SV
AIR91654/0	VALVE,NON RETURN	APB011534X	SV
AIR91656/0	VALVE,NON-RETURN	LK8605119	SV
AIR91656/0	VALVE,NON-RETURN	LK8403967	SV
AIR91658/0	VALVE,NON RETURN	LK8601182	SV
AIR91660/0	VALVE,NON-RETURN	LK8506372	SV
AIR91662/2	VALVE,RELIEF	LK0015	SV
AIR91662/2	VALVE,RELIEF	LK8710838	SV
AIR91662/2	VALVE,RELIEF	LK8808205	SV
AIR91666/0	ACCUMULATOR	LK8608220	SV
AIR91748/1	VALVE,SPOILER SELECTOR	LK8710095	OVH
AIR91748/1	VALVE,SPOILER SELECTOR	LK8201382	OVH
AIR91762-1	VALVE, FLOW CONTROL PTU	LK8708182	INS
AL00103	ACTUATOR	1558	WRE
AL00103	ACTUATOR	1557	REP
ATEST00335-000	PANEL, SWITCH	343/WDFD/00	SV
B00A214268A	VALVE, PRV ISOLATION	PRVL/88/355	SV
B00A214268A	VALVE, PRV ISOLATION	DGH/81/719B	SV
B00A214269A	VALVE,TEMP CONTROL	TCVL/87/187	SV
B00A214272A	VALVE,ANTI-ICE ISOLATION	AIVL/86/121	INS
B01A214271A	VALVE,BLEED AIR RELIEF	DGH/81/7275	TST
B01A214271A	VALVE,BLEED AIR RELIEF	DRVL/86/078	TST
B01A214271A	VALVE,BLEED AIR RELIEF	DRVL/88/403	REP
B01A214271A	VALVE,BLEED AIR RELIEF	HSJ/83/0203	TST
B01A214271A	VALVE,BLEED AIR RELIEF	DRVL/88/348	TST
B01A214271A	VALVE,BLEED AIR RELIEF	DRVL/87/205	REP
B01A214271A	VALVE,BLEED AIR RELIEF	DRVL/86/698	TST
B01A214271A	VALVE,BLEED AIR RELIEF	HSJ/82/1678	SV
B03A214267A	VALVE, DISCHARGE 100-200	146DV19R	SV
B03A214267A	VALVE, DISCHARGE 100-200	146AV17R	SV
B04A218021A	SENSOR, TEMP, BLEED AIR	TSL86/128	SV
B04A218021A	SENSOR, TEMP, BLEED AIR	TSL86/204	SV
B04A218021A	SENSOR, TEMP, BLEED AIR	TSL85/119	SV
B06A213099A	PANEL,PRESSURE CONTROL	DGH85/365	SV
B06A213099A	PANEL,PRESSURE CONTROL	85/021	SV
B06A213099A	PANEL,PRESSURE CONTROL	HSJ/84/1223	SV

B06A213099A	PANEL,PRESSURE CONTROL	HSJ/82/PCP6	SV
B06A213099A	PANEL,PRESSURE CONTROL	DGH/85/364	SV
B1438/1	MOTOR,STICK SHAKER	5713	SV
B1438/1MK8	MOTOR,STICK SHAKER	ATELSTO296	SV
B-345LS	CONTACTOR,AC	CJ-36185	SV
B-345LS	CONTACTOR,AC	CG-12843	SV
B-345LS	CONTACTOR,AC	CG-53584	SV
B-345LS	CONTACTOR,AC	CE-62663	SV
B-345LS	CONTACTOR,AC	CG-20714	SV
BAEREF000025246	DETECTOR,FUSE FAILURE	ASLC0003766	SV
BAEREF000025246	DETECTOR,FUSE FAILURE	ASLC0003767	SV
C14810	RESERVOIR,HYD AIRSTAIR	TR137AR	SV
C14810	RESERVOIR,HYD AIRSTAIR	7RD21A7	SV
C201-1500-1	VALVE,RAIN RPLLNT,SOLEN.	9280	SV
C-81506-3	UNIT,STALL WARNING 200 SERIES	315	SV
C-81506-3	UNIT,STALL WARNING 200 SERIES	620	SV
C-81506-3	UNIT,STALL WARNING 200 SERIES	298	SV
C-81506-3	UNIT,STALL WARNING 200 SERIES	464	SV
C-81506-3	UNIT,STALL WARNING 200 SERIES	301	SV
C-81506-4	UNIT,STALL WARNING 300 SERIES	844	SV
C-81606-5	UNIT,STALL IDENT 200 SERIES	339	SV
C-81606-5	UNIT,STALL IDENT 200 SERIES	508	SV
C-81606-5	UNIT,STALL IDENT 200 SERIES	507	SV
C-81606-5	UNIT,STALL IDENT 200 SERIES	539	SV
C-81606-5	UNIT,STALL IDENT 200 SERIES	179	SV
C-81606-6	UNIT,STALL IDENT 300 SERIES	766	SV
CGAB2020-00	SMOKE DETECTOR	25	SV
D102740	MOTOR,BRAKE COOLING FAN	454774-S	SV
D102740	MOTOR,BRAKE COOLING FAN	4556938	SV
D103549	FAN,HYDRAULIC OIL COOLING	494225	SV
D103549	FAN,HYDRAULIC OIL COOLING	494324	SV
D103549	FAN,HYDRAULIC OIL COOLING	497815	SV
D103549	FAN,HYDRAULIC OIL COOLING	494323	SV
D103549	FAN,HYDRAULIC OIL COOLING	494223	SV
D103549	FAN,HYDRAULIC OIL COOLING	461988S	SV
D104219	AVIONICS COOLING FAN	469859	SV
D1150-10A	COOLER,HEAT EXCHANGER	JM/BA016953	SV
D1150-10A	COOLER,HEAT EXCHANGER	JM/BA016769	SV
D11986	TRANSDUCER,AIRSPD	130910	SV
D11986	TRANSDUCER,AIRSPD	123624	SV
D14624	AIRSTAIR,FWD PASSENGER	A090	SV
D14624	AIRSTAIR,FWD PASSENGER	A017	SV
D17862-105	BOTTLE,EVAC SLIDE (SASSY)	727452 HAZMAT	SV
D17862-105	BOTTLE,EVAC SLIDE (SASSY)	727455 HAZMAT	SV
D17862-105	BOTTLE,EVAC SLIDE (SASSY)	828208 HAZMAT	SV
D17862-105	BOTTLE,EVAC SLIDE (SASSY)	548773 HAZMAT	SV
D17862-105	BOTTLE,EVAC SLIDE (SASSY)	730122 HAZMAT	SV
D17862-105	BOTTLE,EVAC SLIDE (SASSY)	718148 HAZMAT	SV
D17862-105	BOTTLE,EVAC SLIDE (SASSY)	318877 HAZMAT	SV
D17862-105	BOTTLE,EVAC SLIDE (SASSY)	828211 HAZMAT	SV
D183469	CABLE ASSY, CONTROL (SASSY)	NSN/PSA79	INS
D31050-105	SLIDE,EVACUATION (MASSY)	0531	SV

D5342	SOLENOID	K4715	SV
D5342	SOLENOID	K4716	SV
D5342	SOLENOID	K4717	SV
D60151	TRANSDUCER,AIR DATA	126017	SV
D60151	TRANSDUCER,AIR DATA	125095	SV
D60299	TRANSDUCER, ALTITUDE	237005-001	SV
D-7BS	CONTACTOR	CH-84223	SV
D-7BS	CONTACTOR	CJ-21230	SV
D-7BS	CONTACTOR	CG-12174	SV
D92098	FAN,CABIN	43990235	SV
D92098	FAN,CABIN	412148	SV
D92098	FAN,CABIN	KR990401	SV
E-327AD	MONITOR,EXTERNAL POWER	CE-92209	SV
E-327AD	MONITOR,EXTERNAL POWER	CG-10401	SV
E-327AD	MONITOR,EXTERNAL POWER	CK-61656	SV
E-327AD	MONITOR,EXTERNAL POWER	CJ-26059	SV
E-327AD	MONITOR,EXTERNAL POWER	CJ-39641	SV
E-327AD	MONITOR,EXTERNAL POWER	CG-66680	SV
E37040S	DETECTOR,UNDERCURRENT	E951	SV
E37040S	DETECTOR,UNDERCURRENT	E076/R	SV
E37040S	DETECTOR,UNDERCURRENT	E890	SV
E37040S	DETECTOR,UNDERCURRENT	E1416	SV
E37040S	DETECTOR,UNDERCURRENT	E852	SV
E37040S	DETECTOR,UNDERCURRENT	E967	SV
E37040S	DETECTOR,UNDERCURRENT	E851	SV
E37040S	DETECTOR,UNDERCURRENT	E963	SV
E37040S	DETECTOR,UNDERCURRENT	E145	SV
E37040S	DETECTOR,UNDERCURRENT	E386	SV
E37040S	DETECTOR,UNDERCURRENT	E385	SV
E37040S	DETECTOR,UNDERCURRENT	E854	SV
E37043D	DETECTOR,UNDERCURRENT	058E	SV
E37043D	DETECTOR,UNDERCURRENT	046E	SV
E37043D	DETECTOR,UNDERCURRENT	061E	SV
E37043S	DETECTOR,UNDERCURRENT	E805	SV
E42012/1	PLATE	1149E	SV
E42012/1	PLATE	613E	SV
E42012/1	PLATE	715E	SV
E42012/2	PLATE	672E	SV
E42012/2	PLATE	618E	SV
EA50057GB3	VALVE,IN-LINE RELIEF	F3827903	SV
EJF101	VALVE,EPA TANK CK/FLOAT	NA	INS
EJF101	VALVE,EPA TANK CK/FLOAT	NA	SV
EJF101	VALVE,EPA TANK CK/FLOAT	NA	SV
ES113/03	SOLENOID,STALL WARNING	14285	SV
ES113/03	SOLENOID,STALL WARNING	14966	SV
G6206-06	CONTROLLER XPONDER HEAD	244	SV
G6206-06	CONTROLLER XPONDER HEAD	246	SV
G6206-06	CONTROLLER XPONDER HEAD	241	SV
G6206-06	CONTROLLER XPONDER HEAD	484	SV
G6206-06	CONTROLLER XPONDER HEAD	220	SV
G6206-06	CONTROLLER XPONDER HEAD	240	SV
G6206-06	CONTROLLER XPONDER HEAD	245	SV

G-6419-100-002	INDICATOR,HYD PRESSURE	8K362	SV
G-6419-100-002	INDICATOR,HYD PRESSURE	07488	SV
G6481-01	CONTROLLER,VHF NAV	143	SV
G6481-01	CONTROLLER,VHF NAV	15	SV
G6481-01	CONTROLLER,VHF NAV	188	SV
G6990-28	CINTRROLLER/TCAS	882	SV
G6990-28	CINTRROLLER/TCAS	896	SV
H301BDM1	STANDBY HORIZON	6678	SV
H301BDM1	STANDBY HORIZON	5768	SV
H71053	WATER HEATER	14285	SV
HC254B0360-002-5	DOOR,FWD TOILET	NA	SV
HC271H0196-002	ELEVATOR, L/H SCREWJACK	SAAB/HG/192	SV
HC271H0196-004	ELEVATOR, R/H SCREWJACK	SAAB/DH/145	SV
HC271H0196-006	AILERON, SCREWJACK	DHCML2028	SV
HC271H0196-008	ELEVATOR, L/H SCREWJACK	481	SV
HC271H0196-008	ELEVATOR, L/H SCREWJACK	DH-005	SV
HC271H0196-010	ELEVATOR, R/H SCREWJACK	SAAB/HC1732	SV
HC272H0045-002	Q-POT,ELEVATOR FEEL	DH1041	SV
HC272H0078-004	DAMPER	DH1039	SV
HC272H0078-004	DAMPER	DH115	SV
HC272H0078-004	DAMPER	DH139	SV
HC272H0220-010	Q POT ASSY,RUDDER	DH050	SV
HC272H0380-004	JACK ASSY	HA4984	SV
HC273H0250-004	GEARBOX,ELEVATOR TRIM	DH/R2/DH008	SV
HC276H0259-000	DETENT,MOD HCM00402S	DH137	SV
HC276H0259-004	DETENT,MOD HCM00402S	NA	SV
HC282H0083-000	VALVE ASSY-FLOAT	NA	SV
HC282H0083-001	VALVE FLOAT	NA	SV
HC291B0042-000	RESERVOIR	B/DH/712A	SV
HC361C0060-000	DUCT ASSY	N/A	SV
HC361H0083-000	DUCT LH	1C239610	SV
HC361H0083-001	DUCT RH	1B197647M	SV
HC361H0083-001	DUCT RH	1C302803	SV
HC361J0130-008	DUCT LH	1C449518	SV
HC361J0130-012	DUCT LH	1C398130	SV
HC396H0544/002	BOARD, PRINTED CIRCUIT	023	SV
HC396H0544/002	BOARD, PRINTED CIRCUIT	TSE0647-P3	SV
HC396H0544/002	BOARD, PRINTED CIRCUIT	TSE3371A-1	SV
HC396H0544-000	BOARD, PRINTED CIRCUIT	110	SV
HC498J0003-000	DUCT	M5775/14	SV
HC498J0005-000	DUCT EXHAUST-TOP	M9109/16	SV
HC498J0005-000	DUCT EXHAUST-TOP	BB24647	SV
HC498J0025-000	DUCT,APU MIDDLE EXHAUST	BB26061	SV
HC499J0008-004	ELBOW,INLET FAN	NA	SV
HC528B0051-003	FAIRING,MLG RIGHT	FL37/88	SV
HC528H0157-000	HINGE,R/H NLG DOOR	HA4668	SV
HC535H0036-000	PANEL ASSY,FAIRING LH	NA	SV
HC535J0293-006	STRUT	NA	SV
HC535J0293-006	STRUT	NA	SV
HC537H0700-016	RADOME ASSY	DH130	SV
HC551B0217-002	FAIRING TIP	SAAB/DH/196	SV
HC551B0217-002	FAIRING TIP	SAAB/DH/206	SV

HC572H0305-001	TIP ASSY.,R/H	NA	SV
HC572H1476-000	WINGTIP,L/H	NA	SV
HC576C0009-004	TAB ASSY,AILERON SERVO LH	026	SV
HC576C0010-004	TAB ASSY,LH AILERON TRIM	163	SV
HC579L0161-002	LEVER ASSY,TRACK #2 LH	NA	SV
HC579L0161-002	LEVER ASSY,TRACK #2 LH	N/A	SV
HC579L0161-003	LEVER ASSY,TRACK #2 RH	NA	SV
HC579L0161-003	LEVER ASSY,TRACK #2 RH	N/A	SV
HC579L0162-002	LEVER ASSY,TRACK #3 LH	NA	SV
HC579L0162-002	LEVER ASSY,TRACK #3 LH	N/A	SV
HC579L0162-003	LEVER ASSY,TRACK #3 RH	NA	SV
HC579L0162-003	LEVER ASSY,TRACK #3 RH	NA	SV
HC579L0162-003	LEVER ASSY,TRACK #3 RH	N/A	SV
HC579L0172-002	LEVER ASSY,TRACK #4 LH	N/A	SV
HC579L0172-003	LEVER ASSY,TRACK #4,RH	NA	REP
HC579L0172-003	LEVER ASSY,TRACK #4,RH	N/A	SV
HC579L0722-002	FAIRING ASSY,TRACK #2 AFT	B3-DH-2-86	SV
HC579L1202-002	BRACKET,HINGE#1,INBRD TAB	NA	SV
HC579L1206-002	BRACKET	NA	SV
HC579L1214-002	BRACKET	NA	SV
HC579L1218-002	HINGE ASSY	NA	SV
HC579L1218-002	HINGE ASSY	N/A	SV
HC579L1222-002	BRACKET ASSY,HINGE BRG	NA	SV
HC579L1222-002	BRACKET ASSY,HINGE BRG	NA	SV
HC579L1222-002	BRACKET ASSY,HINGE BRG	NA	SV
HC579L1226-002	HINGE BRACKET	NA	SV
HC711H0320-000	FAIRING	NA	SV
HC711H0450-004	RING ASSY,LOWER,QEC100ZK2	NA	SV
HC711H0450-004	RING ASSY,LOWER,QEC100ZK2	NA	SV
HC711H0450-004	RING ASSY,LOWER,QEC100ZK2	NA	SV
HC711H0450-004	RING ASSY,LOWER,QEC100ZK2	NA	SV
HC711H0755-014	FIRE BLKT,QEC 100Z KIT (SASSY)	SB/BAE/0652	SV
HC711H0755-014	FIRE BLKT,QEC 100Z KIT (SASSY)	SB/BAE/0432	SV
HC711H0755-014	FIRE BLKT,QEC 100Z KIT (SASSY)	SB/BAE/0346	SV
HC711H0755-014	FIRE BLKT,QEC 100Z KIT (SASSY)	SB/BAE/0292	SV
HC711H1120-022	DOOR RH	SB/BAE/0608	SV
HC711H8002-000	DOOR ASSY,LEFT FAN DUCT	SE/BAE/0171	SV
HC712H0027-004	BRACKET,MOUNTING	JG16	SV
HC712H0027-004	BRACKET,MOUNTING	JC38	SV
HC712H0027-004	BRACKET,MOUNTING	GL01	SV
HC712H0028-004	BRKT ASSY,MTG QEC100Z K15	JC38	SV
HC712H0028-004	BRKT ASSY,MTG QEC100Z K15	GL01	SV
HC712H0028-004	BRKT ASSY,MTG QEC100Z K15	JG16	SV
HC761H0216-000	SHAFT	NA	INS
HC761H0216-000	SHAFT	NA	SV
HC761H0216-000	SHAFT	NA	SV
HC921B0223-004	PANEL	NA	SV
HC921H0451/000	CIRCUIT BOARD,PRINTED	213	SV
HC921H0451/000	CIRCUIT BOARD,PRINTED	064	SV
HC921H0451/000	CIRCUIT BOARD,PRINTED	026	SV
HC921H0451/000	CIRCUIT BOARD,PRINTED	054	SV
HC921H0451/000	CIRCUIT BOARD,PRINTED	066	SV

HC921H0458/002	ANNUNCIATOR PCB	1720	SV
HC921H0458/002	ANNUNCIATOR PCB	018	SV
HC921H0458/002	ANNUNCIATOR PCB	274	SV
HC921H0458/002	ANNUNCIATOR PCB	1215	SV
HC921H0458/002	ANNUNCIATOR PCB	60	SV
HC921H0595-006	P.C. BOARD, LEFT FWD DOOR	275	SV
HC921H1837-000	RESISTOR BOX ASSY	E2107	SV
HC921H1837-000	RESISTOR BOX ASSY	GE016	SV
HE15201-2	SWITCH,LOW PRESSURE	0784TW	SV
HE15258-1	PRESSURE SWITCH-Y&G ATA27	3890TW	SV
HE71053	HEATER,WATER	106318	SV
HE71053	HEATER,WATER	106939	SV
HE71053	HEATER,WATER	105812	SV
HE83273-1	SWITCH,HYD OVERTEMP	1611TW	SV
HE83273-1	SWITCH,HYD OVERTEMP	1599TW	SV
HTE1451/1	ACTUATOR	884GB103-H	SV
HTE1451-1	ACTUATOR	984GB105H	SV
HTE210014	ACTUATOR- SINGLE MOTOR	184GB207-H	SV
HTE210014	ACTUATOR- SINGLE MOTOR	782GB298/H	SV
HTE210014	ACTUATOR- SINGLE MOTOR	891GB158	SV
HTE210014	ACTUATOR- SINGLE MOTOR	291GB207	SV
HTE210014	ACTUATOR- SINGLE MOTOR	680GB190/H	SV
HTE210014	ACTUATOR- SINGLE MOTOR	M703GB899	SV
HTE210014	ACTUATOR- SINGLE MOTOR	1284GB227/H	SV
HTE210014	ACTUATOR- SINGLE MOTOR	481GB124	SV
HTE210014	ACTUATOR- SINGLE MOTOR	1185GB306/H	SV
HTE210014	ACTUATOR- SINGLE MOTOR	487GB168/H	SV
HTE210014	ACTUATOR- SINGLE MOTOR	488GB337/H	SV
HTE210014	ACTUATOR- SINGLE MOTOR	1185GB318/H	SV
HTE365/4	VALVE,APU NONRETURN AIR	289VNR207	SV
HTE365-4	VALVE,APU NONRETURN AIR	784VNR113R	SV
HTE365-4	VALVE,APU NONRETURN AIR	524VNR100	SV
HTE4344	VALVE,NON-RETURN	183VNR188	SV
HTE4344/1	VALVE,NON-RETURN	486VNR161	SV
HTE4344-1	VALVE,NON-RETURN	185VNR192	SV
HTE4373/2	VALVE,NON-RETURN	780VNR14-3	SV
HTE4373/2	VALVE,NON-RETURN	385VNR166	SV
HTE4373-1	VALVE,NON-RETURN	585VNR121	SV
HTE4373-2	VALVE,NON-RETURN	784VNR130	SV
HTE4373-2	VALVE,NON-RETURN	988VNR1174	SV
HTE4855	VALVE	FR002BD	SV
HTE4855	VALVE	FR003BD	SV
HTE530004	VALVE,TOILET FLUSHING	M132TFV889	SV
HTE530004	VALVE,TOILET FLUSHING	M107TFV1286	SV
HTE530004	VALVE,TOILET FLUSHING	M113TFV986	SV
HTE530004/1	VALVE,TOILET FLUSHING	M110TFV1286	SV
HTE530004/1	VALVE,TOILET FLUSHING	FRTR024AX	SV
HTE530004-1	VALVE,TOILET FLUSHING	FR006BN	SV
HTE530004-1	VALVE,TOILET FLUSHING	M101TFV1286	SV
HTE530004-1	VALVE,TOILET FLUSHING	M106TFV989	SV
HTE690041	SWITCH, LOW PRSSURE (SASSY)	20574	SV
HTE690041	SWITCH, LOW PRSSURE (SASSY)	0191	SV

HTE690042	SWITCH (SASSY)	20184	SV
HTE9082/1	ACTUATOR,FUEL & HYDRAULIC	786GB185/H	SV
HTE9082/1	ACTUATOR,FUEL & HYDRAULIC	1186GB116/H	SV
HTE9082/1	ACTUATOR,FUEL & HYDRAULIC	1184GB106/H	SV
HTE9082/1	ACTUATOR,FUEL & HYDRAULIC	485GB285/H	SV
HTE9082/1	ACTUATOR,FUEL & HYDRAULIC	887GB115/H	SV
HTE9082/1	ACTUATOR,FUEL & HYDRAULIC	1283GB237/H	SV
HTE9082-1	ACTUATOR,FUEL & HYDRAULIC	985GB260/H	SV
HTE9084	ACTUATOR	882GB146/H	SV
HTE9084	ACTUATOR	486GB236/H	SV
HTE9084	ACTUATOR	482GB105/H	SV
HTE9084	ACTUATOR	M178GB699	SV
HTE9181-001	VALVE,BUTTERFLY	386VBF107	SV
HTE9181-001	VALVE,BUTTERFLY	41040530	SV
HTE9526	VALVE	386VPR128	SV
HTE9526	VALVE	585VPR109	SV
HTE9526	VALVE	585VDR102	SV
HTE9526	VALVE	987VPR104	SV
HTE9531-101	VALVE ASSY,3-WAY	588VB-152	SV
HTE9531-101	VALVE ASSY,3-WAY	280VB248	SV
HTE9531-101	VALVE ASSY,3-WAY	118VB140	SV
HTE9531-101	VALVE ASSY,3-WAY	588VB146	SV
HTE9681	VALVE ASSY,HYDRAULIC	585VB197	SV
HTE9681/1	VALVE ASSY,HYDRAULIC	788VB168	SV
HTE9681-1	VALVE ASSY,HYDRAULIC	FRO23BC	SV
HTE9681-1	VALVE ASSY,HYDRAULIC	982VB212	SV
HTE9682	VALVE	585VB155	SV
HTE9682	VALVE	1085VB120	SV
HTE9683	VALVE,PTU/STALL-RPLZS	489VB132	SV
HTE9683	VALVE,PTU/STALL-RPLZS	886VB136	SV
HTE9683	VALVE,PTU/STALL-RPLZS	990VB145	SV
HTE9683	VALVE,PTU/STALL-RPLZS	FR060BC	SV
HTE9783/1	VALVE,RELIEF	38VPR123/R	SV
HTE9783/1	VALVE,RELIEF	E2018	SV
HTE9783/1	VALVE,RELIEF	E2017	SV
HTE9783/1	VALVE,RELIEF	783VPR113	SV
HTE9783-1	VALVE,RELIEF	686VPR106	SV
K38999/1	OXYGEN STORAGE ASSY	1114	SV
K38999/1	OXYGEN STORAGE ASSY	302	SV
K38999/A	OXYGEN STORAGE ASSY	1115	SV
K38999/A	OXYGEN STORAGE ASSY	472	SV
K38999-1	OXYGEN STORAGE ASSY	1977	SV
K38999-1	OXYGEN STORAGE ASSY	1101	SV
K38999-1A	OXYGEN STORAGE ASSY	1992	SV
K38999-1A	OXYGEN STORAGE ASSY	1945	SV
K38999-1A	OXYGEN STORAGE ASSY	1953	SV
K38999-1A	OXYGEN STORAGE ASSY	2007	SV
K38999-1A	OXYGEN STORAGE ASSY	1980	SV
K38999-1A	OXYGEN STORAGE ASSY	1990	SV
K38999-1A	OXYGEN STORAGE ASSY	1060	SV
K38999-1A	OXYGEN STORAGE ASSY	1970	SV
K38999-1A	OXYGEN STORAGE ASSY	1987	SV

K38999-1A	OXYGEN STORAGE ASSY	1330	SV
K38999-1A	OXYGEN STORAGE ASSY	1991	SV
K38999-1A	OXYGEN STORAGE ASSY	1956	SV
K38999-1A	OXYGEN STORAGE ASSY	1972	SV
K38999-1A	OXYGEN STORAGE ASSY	1950	SV
K38999-1A	OXYGEN STORAGE ASSY	1966	SV
K38999-1A	OXYGEN STORAGE ASSY	1996	SV
K38999-1A	OXYGEN STORAGE ASSY	1976	SV
K38999-1A	OXYGEN STORAGE ASSY	2012	SV
K38999-1A	OXYGEN STORAGE ASSY	1961	SV
K38999-1A	OXYGEN STORAGE ASSY	1307	SV
K38999-1A	OXYGEN STORAGE ASSY	167	SV
K38999-1A	OXYGEN STORAGE ASSY	1957	SV
K38999-1A	OXYGEN STORAGE ASSY	1949	SV
K38999-1A	OXYGEN STORAGE ASSY	1958	SV
K38999-1A	OXYGEN STORAGE ASSY	2011	SV
K38999-2	OXYGEN STORAGE ASSY	166	SV
K38999-2A	OXYGEN STORAGE ASSY.	227	SV
K38999-2A	OXYGEN STORAGE ASSY.	217	SV
K38999-2A	OXYGEN STORAGE ASSY.	216	SV
K38999-2A	OXYGEN STORAGE ASSY.	186	SV
K38999-2A	OXYGEN STORAGE ASSY.	120	SV
K38999-2A	OXYGEN STORAGE ASSY.	187	SV
K38999-2A	OXYGEN STORAGE ASSY.	213	SV
K38999-2A	OXYGEN STORAGE ASSY.	179	SV
K38999-2A	OXYGEN STORAGE ASSY.	206	SV
K38999-2A	OXYGEN STORAGE ASSY.	223	SV
K38999-2A	OXYGEN STORAGE ASSY.	219	SV
K38999-2A	OXYGEN STORAGE ASSY.	223	SV
K38999-2A	OXYGEN STORAGE ASSY.	203	SV
K38999-2A	OXYGEN STORAGE ASSY.	199	SV
K38999-2A	OXYGEN STORAGE ASSY.	211	SV
K38999-2A	OXYGEN STORAGE ASSY.	181	SV
K38999-2A	OXYGEN STORAGE ASSY.	204	SV
K38999-2A	OXYGEN STORAGE ASSY.	184	SV
K38999-2A	OXYGEN STORAGE ASSY.	198	SV
K38999-2A	OXYGEN STORAGE ASSY.	170	SV
K38999-2A	OXYGEN STORAGE ASSY.	463	SV
K38999-2A	OXYGEN STORAGE ASSY.	233	SV
K38999-2A	OXYGEN STORAGE ASSY.	122	SV
K38999-2A	OXYGEN STORAGE ASSY.	114	SV
K38999-2A	OXYGEN STORAGE ASSY.	221	SV
K38999-2A	OXYGEN STORAGE ASSY.	445	SV
K38999-2A	OXYGEN STORAGE ASSY.	252	SV
K38999-2A	OXYGEN STORAGE ASSY.	173	SV
K38999-2A	OXYGEN STORAGE ASSY.	497	SV
K38999-2A	OXYGEN STORAGE ASSY.	228	SV
K38999-2A	OXYGEN STORAGE ASSY.	229	SV
K95677	INDICATOR,PSSNGR SUPPLY	PS000159	SV
K95677	INDICATOR,PSSNGR SUPPLY	A0126130	SV
KCA0105W	COMPASS,STANDBY	SAV13679	SV
KCA0105W	COMPASS,STANDBY	SAV13520	SV

KCA-0105W	COMPASS,STANDBY	SAV13622	SV
KCA-0105W	COMPASS,STANDBY	SAV22229	SV
KCA-0105W	COMPASS,STANDBY	SAV8665	SV
M811B24	CLOCK, DIGITAL	22637	SV
MAP903-001	VALVE, PRV ISOLATION	DGH817105	SV
MAP903-001	VALVE, PRV ISOLATION	HSJ831015	SV
MC10-06-100	MASK, CREW O2	7092	SV
MC10-06-100	MASK, CREW O2	16758	SV
MC10-06-100	MASK, CREW O2	8461	SV
MI-585162-2	INDICATOR,RADAR	2771	TST
MI-585162-2	INDICATOR,RADAR	2982	TST
MI-585162-2	INDICATOR,RADAR	3080	TST
MI-585162-2	INDICATOR,RADAR	3133	SV
MI-585162-2	INDICATOR,RADAR	2556	SV
MI-585162-2	INDICATOR,RADAR	2868	SV
MI-585162-2	INDICATOR,RADAR	2657	SV
MI-585162-2	INDICATOR,RADAR	2279	SV
MI-585162-2	INDICATOR,RADAR	2315	SV
MI-585164	ANTENNA,RADAR	1789	SV
MI-585164	ANTENNA,RADAR	2887	SV
MI585167	SWITCH,RADAR WAVEGUIDE	1334	SV
MI585167	SWITCH,RADAR WAVEGUIDE	0623	SV
MI-585167	SWITCH,RADAR WAVEGUIDE	0959-0389	SV
MXP127	STOWAGE BOX,02 MASK	6138	SV
MXP127	STOWAGE BOX,02 MASK	4267	SV
MXP127	STOWAGE BOX,02 MASK	7460	SV
NC82024	HARNESS AFT PAX DR WR	NC02762/04	SV
NC82024	HARNESS AFT PAX DR WR	NC0614/01	SV
NC82024	HARNESS AFT PAX DR WR	NC2770/04	SV
ND0075-1764	NETWORK	L244684	NEW
ND0075-1764	NETWORK	L246104	NEW
ND0075-1764	NETWORK	L173740	REP
NF0075/2600	CONTROLLER,WNDSCRN/DEMIST	L206667	TST
NF0075/2600	CONTROLLER,WNDSCRN/DEMIST	L172885	SV
NF0075-1705	DETECTOR,ICE	L154616	SV
NF0075-1705	DETECTOR,ICE	L248507	SV
NF0075-2600	CONTROLLER,WNDSCRN/DEMIST	L206493	REP
NF0075-2600	CONTROLLER,WNDSCRN/DEMIST	L205368	TST
NF0075-3600	CONTROLLER,WNDSCRN/DEMIST	L325099	TST
NF0075-3600	CONTROLLER,WNDSCRN/DEMIST	L247124	INS
NF0075-3600	CONTROLLER,WNDSCRN/DEMIST	L249349	INS
NF0075-3600	CONTROLLER,WNDSCRN/DEMIST	L325276	REP
NF20216-155	WINDOW, LEFT D.V.	L322546	SV
NF20216-155	WINDOW, LEFT D.V.	L325509	SV
NF20216-155	WINDOW, LEFT D.V.	L328718	SOLD
NF20216-155	WINDOW, LEFT D.V.	L323378	SOLD
NF20216-155	WINDOW, LEFT D.V.	L322680	SV
NF20216-156	WINDOW, RIGHT D.V.	L310111	SV
NF20216-156	WINDOW, RIGHT D.V.	L322848	SV
NF20216-156	WINDOW, RIGHT D.V.	L323381	SV
NF20216-156	WINDOW, RIGHT D.V.	L323257	SV
NF20216-156	WINDOW, RIGHT D.V.	L325879	SOLD

NF20216-402	WINDSHLD,RIGHT OUTER	L328964	SV
NF20216-402	WINDSHLD,RIGHT OUTER	L328874	SV
NF20216-402	WINDSHLD,RIGHT OUTER	L317786	SV
NF20216-402	WINDSHLD,RIGHT OUTER		SV
NF20216-525	WINDSHLD,LEFT INNER	L337929	SV
NF20216-526	WINDSHLD,RIGHT INNER	L337943	SV
NP-170101-3	WINDSHLD,LEFT INNER	06051H7799	SV
NP-170101-3	WINDSHLD,LEFT INNER	04342H3949	SV
NP-170101-4	WINDSHLD,RIGHT INNER	06037H6269	SV
NP-170102-1	WINDSHLD,LEFT OUTER	04313H1496	SV
NP-170102-1	WINDSHLD,LEFT OUTER	04243H5020	SV
P308-45-0102	JACK,LIFT SPOILER	DBPBAE5714	SV
P308-45-0202	JACK,LIFT SPOILER	AAA001P308	SV
P310-45-0002	DAMPER, GUST ELEV	DBPBAEE113	SV
P310-45-0002	DAMPER, GUST ELEV	DBPBAEE49	SV
P311-45-0002	DAMPER, GUST AILERON	A226	SV
P311-45-0002	DAMPER, GUST AILERON	DBPBAEA246	SV
PC-250	INVERTER,STATIC	4206	SV
PC-250	INVERTER,STATIC	2909	SV
PC-250	INVERTER,STATIC	3326	SV
PDCR330-1028	TRANSDUCER,OIL PRESSURE(SASSY)	1263391	SV
PDCR330-1028	TRANSDUCER,OIL PRESSURE(SASSY)	1851567	SV
PDCR330-1028	TRANSDUCER,OIL PRESSURE(SASSY)	1830342	SV
PDCR330-1028	TRANSDUCER,OIL PRESSURE(SASSY)	1930344	INS
PDCR330-1028	TRANSDUCER,OIL PRESSURE(SASSY)	2081294	INS
PDCR330-1028	TRANSDUCER,OIL PRESSURE(SASSY)	1148690	SV
PDCR330-1028	TRANSDUCER,OIL PRESSURE(SASSY)	2150363	SV
PDCR330-1028	TRANSDUCER,OIL PRESSURE(SASSY)	874929	TST
PDCR330-1028-M0	TRANSDUCER,OIL PRESSURE(SASSY)	742 598	SV
PDCR330-1028-M0	TRANSDUCER,OIL PRESSURE(SASSY)	1443820	SV
QP122B	PITOTHEAD,Q FEEL	373/00	SV
QP122B	PITOTHEAD,Q FEEL	387/00	SV
SC2253A	DECODER,SELCAL	386	REP
SD113G	CONTACTOR,ENGINE START	CN-12134	SV
SD113G	CONTACTOR,ENGINE START	CM-85236	SV
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1012	SV
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1174A	SV
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1324A	INS
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1157A	INS
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1043A	INS
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1292A	INS
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1144A	INS
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1133A	REP
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1074A	INS
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1215A	INS
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1302A	REP
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1179A	SV
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1180A	SV
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1301A	SV
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1142A	SV
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1358A	SV
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1208A	SV

SLZ7003A	INDICATOR,VERTICAL SPEED	TH1371A	SV
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1331A	SV
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1303A	SV
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1160A	SV
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1057A	SV
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1305A	SV
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1175	INS
SLZ7003A	INDICATOR,VERTICAL SPEED	TH1346A	INS
SM601BA20A13	CIRCUIT BREAKER	01499	NEW
SM601BA40A14	CIRCUIT BREAKER,GALLEY	01913	SV
STD458-3	VALVE,PURGE	NA	SV
STD458-3	VALVE,PURGE	NA	SV
TDR503-146	RELAY,TIME DELAY	FR3880	NEW
WKA36684/2	VALVE,ISOLATION,R/H ONLY	1924	SV
WKA36684/2	VALVE,ISOLATION,R/H ONLY	1961	SV
WKA36684/2	VALVE,ISOLATION,R/H ONLY	1507	SV
WKA36685	VALVE,02 PRESS.REDUCING	262	OVH
WKA36686	VALVE	269	OVH
WKA36686	VALVE	208	OVH
WKA36692/1	BOTTLE,PAX O2 (UN1072)	1951130 HAZMAT	SV
WKA36692-1	BOTTLE,PAX O2 (UN1072)	1304184 HAZMAT	SV
WKA36692-1	BOTTLE,PAX O2 (UN1072)	1742949 HAZMAT	SV
WKA36693/2	BOTTLE,FIXED O2(UN1072)	Z93664 HAZMAT	SV
WKA36693/2	BOTTLE,FIXED O2(UN1072)	67839Y HAZMAT	SV
WL/0201KID/3	INDICATOR,FUEL QTY	TT2550	OVH
WL/1107AM/MS/4	ALTIMETER, SERVO	AF406	SV
WL-0101KID-2	INDICATOR,FUEL QTY	83010064	SV
WL0201KID/3	INDICATOR,FUEL QTY	TT4128	SV
WL0201KID/4	INDICATOR,FUEL QTY	TT650	REP
WL106AMA20	INDICATOR,MACH AIRSPEED	AH483	REP
WL106AMA20	INDICATOR,MACH AIRSPEED	AH516	SV
WL106AMA20	INDICATOR,MACH AIRSPEED	AH480	SV
WL106AMA7	MACH/AIRSPEED INDICATOR	AH438	REP
WL106AMA7	MACH/AIRSPEED INDICATOR	AH552	REP
WL1107AM/MS/4	ALTIMETER, SERVO	A7590	SV
WL1107AM-MS4	ALTIMETER, SERVO	AF168	SV
WL1107AM-MS4	ALTIMETER, SERVO	AG159	SV
WL1107AM-MS4	ALTIMETER, SERVO	AF506	SV
WL1107AM-MS4	ALTIMETER, SERVO	AF907	SV
WL1107AM-MS4	ALTIMETER, SERVO	AG372	SV
WL1107AM-MS4	ALTIMETER, SERVO	AF531	REP
WL1704AM1	ALTIMETER, STANDBY	AE779	REP
WL1704AM1	ALTIMETER, STANDBY	AE730	SV
WL1704AM1	ALTIMETER, STANDBY	AE540	SV
WL1704AM1	ALTIMETER, STANDBY	AE601	SV
WL1704AM1	ALTIMETER, STANDBY	AE433	REP
WL604AMA22	INDICATOR,MACH AIRSPEED	AH675	SV
WL604AMA23	INDICATOR MACH SPEED	AJ283	INS
WL651RSA4	INDICATOR,N2	AH181	REP
WL651RSA5	INDICATOR,N2	AC249	SV
WL651RSA5	INDICATOR,N2	AF483	REP
WL651RSA5	INDICATOR,N2	AE136	TST

WL651RSA5	INDICATOR,N2	AD777	REP
WL651RSA5	INDICATOR,N2	AH139	REP
WL651RSA5	INDICATOR,N2	AF819	REP
WL706RSA5	INDICATOR,TURBNE GAS TEMP	AE440	REP
WL706RSA5	INDICATOR,TURBNE GAS TEMP	AD412	REP
WL706RSA5	INDICATOR,TURBNE GAS TEMP	AJ428	SV
WL706RSA5	INDICATOR,TURBNE GAS TEMP	AH511	OVH
WL719RSA1	INDICATOR,N1% RPM	AJ467	SV
WL719RSA1	INDICATOR,N1% RPM	AH249	SV
WL719RSA1	INDICATOR,N1% RPM	AH917	REP
WL719RSA1	INDICATOR,N1% RPM	AH456	REP
WP207	PUMP,WINDSCREEN WASHING	J64-84	OVH
WP207	PUMP,WINDSCREEN WASHING	C389-85	OVH
XC5577	HEATER,TRIM DAMPER	346	SV
XD5423	DUCT	NA	SV
XD5423	DUCT	NA	SV
ZP100	PORTABLE O2 BOTTLE	50251 HAZMAT	SV
05K146001	KIT-I/H,ALL NUMBERED INSP	AWAC5	NEW
05K146001	KIT-I/H,ALL NUMBERED INSP	AWAC1	NEW
05K146001	KIT-I/H,ALL NUMBERED INSP	AWAC3	NEW
05K146001	KIT-I/H,ALL NUMBERED INSP	AWAC2	NEW
05K146001	KIT-I/H,ALL NUMBERED INSP	AWAC4	NEW
066-1056-01	TRANSPONDER 200 KING	3260	SV
066-1056-01	TRANSPONDER 200 KING	3112	SV
066-1056-01	TRANSPONDER 200 KING	3207	SV
066-1056-01	TRANSPONDER 200 KING	364	SV
066-1056-01	TRANSPONDER 200 KING	3984	SV
066-1056-01	TRANSPONDER 200 KING	3320	SV
066-1056-01	TRANSPONDER 200 KING	2929	SV
066-1056-01	TRANSPONDER 200 KING	3727	SV
066-1056-01	TRANSPONDER 200 KING	4022	SV
066-1056-01	TRANSPONDER 200 KING	3817	SV
066-1056-01	TRANSPONDER 200 KING	3658	SV
066-1123-00	TRANSPONDER 300	1414	SV
066-1123-00	TRANSPONDER 300	1145	SV
066-1123-00	TRANSPONDER 300	1245	SV
066-1123-00	TRANSPONDER 300	1225	SV
066-1123-00	TRANSPONDER 300	P1176	SV
066-1123-00	TRANSPONDER 300	1401	SV
066-1123-00	TRANSPONDER 300	1416	SV
066-1123-00	TRANSPONDER 300	1439	SV
066-1123-00	TRANSPONDER 300	1402	SV
066-1123-00	TRANSPONDER 300	1209	SV
066-1123-00	TRANSPONDER 300	1448	SV
066-1123-00	TRANSPONDER 300	1249	SV
1U458-001	CONTROLLER,TRANSPONDER	T153A	SV
1U458-001	CONTROLLER,TRANSPONDER	T135	SV
1U458-001	CONTROLLER,TRANSPONDER	T233A	SV
1U458-001	CONTROLLER,TRANSPONDER	T164A	SV
2-043-150-15	FAN ROTOR SHROUD (SASSY)	18671-17	OVH
2-100-040-47	4TH VANE ASSY (SASSY)	A475	SV
2-101-640-31	#2 BRNG HOUSNG,SB 72-0076	NA	SV

2-101-650-27	RETAINER ASSY/FWD SEAL	NA	SV
2-121-470R54	CYLINDER,1ST STAGE G.P (SASSY)	0218847	SV
21K146002	KIT-I/H,A/C PACK CLEANING	AWAC1	NEW
21K146002	KIT-I/H,A/C PACK CLEANING	AWAC3	NEW
21K146002	KIT-I/H,A/C PACK CLEANING	AWAC2	NEW
21M27-13	SWITCH,FLOW INDICATOR	V35520A	SV
2-203-250-01	BLADE SET,1=2 BLADES	NA	SV
2-303-052-04	OVERSPEED CONTROL (SASSY)	050130704023	SV
2-303-052-04	OVERSPEED CONTROL (SASSY)	060130704038	SV
2-303-769-02	IGNITOR LEAD ASSY (SASSY)	996971101196	SV
2-303-769-03	IGNITOR LEAD ASSY (SASSY)	056971100185	SV
2-303-769-03	IGNITOR LEAD ASSY (SASSY)	046971100943	SV
24K146001	KIT-I/H,IDG BLANKING KIT	AWAC1	NEW
24K146001	KIT-I/H,IDG BLANKING KIT	AWAC3	NEW
24K146001	KIT-I/H,IDG BLANKING KIT	AWAC2	NEW
24K146001	KIT-I/H,IDG BLANKING KIT	AWAC4	NEW
2594661-803	RADIO MAG INDICATOR	85070978	SV
2594661-803	RADIO MAG INDICATOR	81090721	SV
32K146002	KIT,E/O E92/067/632	AWAC1	NEW
3862200-3	FAN ASSY (SASSY)	P-446C	SV
3888000-2	IGNITOR UNIT,APU (SASSY)	990218000844	SV
4045147-906	INDICATOR,HSI	82080175	SV
4045147-906	INDICATOR,HSI	82050147	SV
4204002	UNIT, POWER TRANSFER/PTU	Y99	SV
49K146001	KIT-I/H,APU INSP CARD 466	AWAC3	NEW
49K146001	KIT-I/H,APU INSP CARD 466	AWAC4	NEW
49K146001	KIT-I/H,APU INSP CARD 466	AWAC5	NEW
49K146001	KIT-I/H,APU INSP CARD 466	AWAC1	NEW
49K146001	KIT-I/H,APU INSP CARD 466	AWAC2	NEW
503/1/06680/003	GENERATOR ONLY,AC	TA739	SV
622-2224-001	TRANSPONDER MODE C	6744	SV
622-2224-001	TRANSPONDER MODE C	6770	SV
7216-3000-3	ANALOG BRNG UNIT 100-200	141	SV
7216-3000-3	ANALOG BRNG UNIT 100-200	013	SV
7216-3000-3	ANALOG BRNG UNIT 100-200	150	SV
7216-3000-3	ANALOG BRNG UNIT 100-200	010	SV
7216-3000-3	ANALOG BRNG UNIT 100-200	204	SV
7216-3000-4	ANALOG BRNG UNIT 100-200	288	SV
7216-3000-4	ANALOG BRNG UNIT 100-200	289	SV
7216-3000-4	ANALOG BRNG UNIT 100-200	327	SV
7216-3000-4	ANALOG BRNG UNIT 100-200	292	SV
7216-3000-4	ANALOG BRNG UNIT 100-200	278	SV
7216-3000-4	ANALOG BRNG UNIT 100-200	288	SV
7216-3000-4	ANALOG BRNG UNIT 100-200	287	SV
72K146001	KIT-I/H,HOT SECTION INSPC	AWAC2	NEW
72K146001	KIT-I/H,HOT SECTION INSPC	AWAC4	NEW
72K146002	KIT-I/H,ENGINE CHANGE	AWAC2	NEW
72K146002	KIT-I/H,ENGINE CHANGE	AWAC3	NEW
72K146002	KIT-I/H,ENGINE CHANGE	AWAC1	NEW
72K146005	KIT-I/H,FUEL MNFLD;33&-34	AWAC1	NEW
72K146005	KIT-I/H,FUEL MNFLD;33&-34	AWAC4	NEW
72K146005	KIT-I/H,FUEL MNFLD;33&-34	AWAC2	NEW

72K146005	KIT-I/H,FUEL MNFLD;33&-34	AWAC3	NEW
72K146006	KIT,3-ENGINE FERRY	AWAC6	NEW
72K146006	KIT,3-ENGINE FERRY	AWAC1	NEW
72K146006	KIT,3-ENGINE FERRY	AWAC5	NEW
72K146006	KIT,3-ENGINE FERRY	AWAC2	NEW
72K146006	KIT,3-ENGINE FERRY	AWAC3	NEW
72K146006	KIT,3-ENGINE FERRY	AWAC4	NEW
75K146001	KIT-I/H,B/BAND ACTUATOR	AWAC1	NEW
75K146001	KIT-I/H,B/BAND ACTUATOR	AWAC2	NEW
805D0602-00	DME/TACAN TRANSCEIVER	150	SV
805D0602-00	DME/TACAN TRANSCEIVER	154	INS
805D0670	BEARING UNIT ADAPTER	101	SV
805D0670	BEARING UNIT ADAPTER	102	SV
805D0670	BEARING UNIT ADAPTER	104	SV
805D0670	BEARING UNIT ADAPTER	103	SV
805D0680	RANGE UNIT ADAPTER	101	SV
805D0680	RANGE UNIT ADAPTER	103	SV
805D0680	RANGE UNIT ADAPTER	104	SV
805D0680	RANGE UNIT ADAPTER	102	SV
83K146001	KIT-I/H,ACCSSRY G/B REBLD	AWAC2	NEW
83K146001	KIT-I/H,ACCSSRY G/B REBLD	AWAC1	NEW
83K146001	KIT-I/H,ACCSSRY G/B REBLD	AWAC3	NEW
83K146002	KIT-I/H,ACCSSRY G/B CHNG	AWAC1	NEW
98.AA1.542	FAN,AVIONICS COOLING	355613	SV
98.AA1.542	FAN,AVIONICS COOLING	4344505	SV
98AA1542	FAN,AVIONICS COOLING	417432	SV
A-957CSD	CONTACTOR,DC	CH-91886	SV
AE20556	CONTROL BOX,ANTI-SKID	KZ023	SV
AHA2332-2	BRAKE ASSY,CARBON 200-300 1/3	Hub only	SV
AIR91658/0	VALVE,NON RETURN	LK8601181	SV
AIR91666/0	ACCUMULATOR	LK8402043	SV
E37043	DETECTOR,UNDERCURRENT	E110	SV
E37043	DETECTOR,UNDERCURRENT	E089	SV
K38999-1A	OXYGEN STORAGE ASSY	1998	SV
K38999-1A	OXYGEN STORAGE ASSY	1983	SV
K38999-1A	OXYGEN STORAGE ASSY	1951	SV
K38999-1A	OXYGEN STORAGE ASSY	309	SV
K38999-2A	OXYGEN STORAGE ASSY.	169	SV
WL651RSA5	INDICATOR, N2	CAE410	SV