

BOEING P/N	DESCRIPTION	S/N	COND
2588838	POSITION SENSOR	238514	AR
8DJ81	INDICATOR; ELECTRICAL TACHOMETER	P3498	AR
231-2	WINDOW HEAT CONTROL	115	AR
P66086	TRANSMITTER PRESSURE RATIO	X-48	AR
32-2861-001	VALVE AIR SHUT OFF	C5-266	AR
AIN-102A	DME INDICATOR	1503	AR
384453-001	TRANSISTORIZED VOLUMETRIC	41875	AR
500-0001-1	COFFEE MAKER	5518	AR
F61C0058MI	VALVE, AIR SHUTOFF	4579	AR
384453-001	TRANSISTORIZED VOLUMETRIC	2678-RSAC	AR
XW21161-16	MOTOR, CONVERTER ASSEMBLY	4470	AR
AIN-102A	DME INDICATOR	1141	AR
114029	INDICATOR, TRIM AIR	12K6249	AR
SLZ9145	VERTICAL SPEED INDICATOR	VY35790	AR
93-A152-20	COCKPIT VOICE RECORDER	82060	AR
114029	INDICATOR, TRIM AIR	72K6630	AR
LKCB-8038	INDICATOR, VOLT METER	522	AR
124838	INDICATOR, TEMPERATURE	644075	AR
182936	INDICATOR, OXYGEN PRESSURE	11179	AR
SRL-04L	INDICATOR, OIL PRESSURE	9217	AR
162BL704D	TEMPERATURE INDICATOR	400	AR
114029	INDICATOR, TRIM AIR	73L2501	AR
10-60712-11	AIRSPEED INDICATOR	492	AR
A3943910001	DUAL ALTIMETER DIFFERENTIAL PRESS IND.	217	AR
96774-18-1299-4	INDICATOR, FLAT POSITION	2	AR
182936	INDICATOR, OXYGEN PRESSURE	2740211	AR
69-30655-5	YAW DAMPER	UNK	AR
114029	INDICATOR, TRIM AIR	73M3621	AR
36155-1AF25A2	RADIO MAG COMPASS INDICATOR	6041000	AR
123674-1-1	CHECK VALVE	P-1055	AR
541248-3	ROTARY ACTUATOR	121-2130	AR
393026-043	INDICATOR, TOTALIZER	M161	AR
124837	INDICATOR	75E8460	AR
152BL802	INDICATOR	A1875	AR
162BL-704D	TEMP. ELECTRICAL RESISTANCE INDICATOR	A91	AR
522-4114-008	RADIO ALTITUDE INDICATOR	3301	AR
98087	THERMAL TURB. INLET SWITCH	2685	AR
2589419-902	MASTER FLUX VALVE	88128167	AR
69-1597-1-18	ENGINE INLET	NA	AR
3205-21	FLUSH MOTOR	7-1353	AR
18423-11	THERMOSTAT	Oct-69	AR
97896	TEMP SENSOR	2414-1A	AR
393026-03236	TRANSISTORIZED AMPLIFER	MS829D	AR
40-533	WHEEL TRANSDUCER	11684	AR
SSRL-07AM	INDICATOR PNEU BRAKE PRESS	549	AR
163BL501C	TEMPERATURE ELECTRICAL RESISTANCE IND	86	AR
69-18153-9	SERVICE INTERPHONE	UNK	AR
344C-1K	INSTRUMENT AMPLIFIER	108	AR
162BL504	TEMP ELECTRICAL RESISTANCE INDICATOR	F1322	AR
8921082G1	WATER HEATER ASSY.	3783	AR
548376-3	CONTROL TEMPERATURE	910-815	AR

2591202-911	COMPASS CONTROLLER	78073415	AR
81001-2A	SPEAKER	1283	AR
KMA1001W	MACH METER	NT1124	AR
6-1169	VHF NAVIGATOR VHF COMM.	221	AR
69-17317-81	PITOT STATIC HEATER MONITOR	323	AR
22-IN-0747	INDICATOR	UNK	AR
2591202-911	COMPASS CONTROLLER	4030618	AR
SRL-07BZ	INDICATOR, PRESSURE	6613	AR
B712-4	IND. HYD. OIL QTY.	B9049-36	AR
544494-1-1	ACTUATOR, ROTARY	58-2128	AR
21450-14	CYLINDER HYDRAULIC POWER CONTROL	462-448	AR
500-0001-1	COFFEE MAKER	5437	AR
21450-14	CYLINDER HYDRAULIC POWER CONTROL	455090	AR
LKCB-18032	AMMETER- A.C.	181	AR
G-1133-1	LE FLAP-SLAT DISPLAY	470	AR
548382-2	SELECTOR TEMPERATURE	1000-2749	AR
162BL-505	TEMPERATURE ELECTRICAL RESISTANCE IND	D213	AR
10-60757-24	DC AMMETER	803676	AR
32026	DIFFERENTIAL PRESS SWITCH	019-1	AR
28000-17	REGULATOR, DILUTER DEMAND	827	AR
7006622	LOAD CONTROLLER	1518	AR
10-60133-5	TEMP SENSOR	937	AR
851CM	PITOT TUBE	110573	AR
548382-2	SELECTOR TEMPERATURE	024C-240	AR
69-31331-7	SWITCH	69-31331-7	AR
G-3261A	ALTITUDE WARNING	208	AR
2594618-901	INDICATOR, TRUE AIR SPEED	82050624	AR
1784460-655	COMPASS INDICATOR	31607	AR
G-1162E	VHF NAVIGAOTR VHF COMM.	221	AR
C5355100141	POTENTIOMETER ASSEMBLY BAROMETRIC SE	239	AR
436-2	GROUND FAULT DETECTOR	1033	AR
182936	INDICATOR, OXYGEN PRESSURE	7776	AR
SRL-07AG	PRESSURE INDICATOR	33	AR
511000	SHUTOFF VALVE SOLENOID	397	AR
525374	ROTARY ACTUATOR	12--3577	AR
65-26445-1	RESERVOIR, HYD SYS B	UNK	AR
525374	ROTARY ACTUATOR	43-3822	AR
858720	VALVE, CHECK	UNK	AR
129700-08	ASSEMBLY ROTARY ACTUATOR	0476-05AA	AR
65-3933	DAMPNER	DLHL1793	AR
V3900-11	VALVE SHUT OFF	13072	AR
40-533	WHEEL TRANSDUCER	153	AR
7551901	FILTER, FLUID PRESSURE	546A	AR
40-533	WHEEL TRANSDUCER	10985	AR
819520	HYDRAULIC GAGE, SNUBBER	1664	AR
398540-2-1	VALVE BUTTERFULY	P-3390	AR
398540-2-1	VALVE BUTTERFULY	P-263	AR
BAC27DCT-171	ACTUATOR, GROUND SPEED BRAKE	984	AR
8921082G1	WATER HEATER ASSY.	6159	AR
8DJ88	INDICATOR; RATE OF FLOW, FUEL	C0498	AR
RC-20-ILB	INDICATOR RATE OF CLIMB	3966	AR
162BL704D	TEMPERATURE INDICATOR	470	AR

SRL-07CA	HYD BRAKE PRESS INDICATOR	5812	AR
10-60554-4	HYD OIL QTY INDICATOR	B0638	AR
69-25893-6	AFT CABIN ZONE TEMP	UNK	AR
260582	ELEVATOR AND RUDDER INDICATOR	579	AR
SRL-04G	OIL PRESSURE INDICATOR	92	AR
162BL701	TEMPERATURE INDICATOR	G-1744	AR
10-60791-12	FLAP POSITION INDICATOR	0007G	AR
65-60212-11	LEADING EDGE POSITION	R00122	AR
AIN-102C	INDICATOR, DME	1565	AR
124836	WATT VAR METER	9G3949	AR
152BL801E	INDICATOR, EXHAUST TEMP	1298	AR
393020-003	TRANSISTORIZED AMLIFIER	M2587C	AR
10118-1	UNIT, OPERATING POWER	1365	AR
SRL-078M	INDICATOR, PNE BRAKE PRESSURE	5641	AR
40-533	WHEEL TRANSDUCER	1413	AR
607510-2	TEMPERATURE CONTROL	025C-2599	AR
2588302-4	DIRECTIONAL GYROSCOPE	80124730	AR
AE-7693-127N2	FILTER, 2 STAGE HYDRAULIC FILTER	2225	AR
384453-001	TRANSISTORIZED VOLUMETRIC	3982US	AR
69-16267	HYDRAULIC SYSTEM A	UNK	AR
393026-042	TRANSISTORIZED AMPLIFIER/ IND. BRIDGE	M894	AR
572757-1	THERMAL TURBINE INLET SWITCH	345	AR
161BL501	TEMPERATURE ELECTRICAL INDICATOR	B73	AR
393025-03236	TRANSISTORIZED AMPLIFIER	9290G	AR
436-2	GROUND FAULT DETECTOR	1679	AR
548382-2	SELECTOR TEMPERATURE	028C-2463	AR
607510-2	TEMPERATURE CONTROL	029C-1148	AR
40-533	WHEEL TRANSDUCER	464	AR
10-60757-28	TEMPERATURE INDICATOR	74C42	AR
163BL501C	TEMPERATURE ELECTRICAL RESISTANCE IND	97	AR
P660A6	TRANSDUCER, PRESSURE RATIO	P-158	AR
40TP13-5	AC MOTOR	1460	AR
65-0015-38-4	FLUSH MOTOR	2	AR
6562	VALVE FUEL SHUT OFF	4034	AR
32-2861-001	VALVE AIR SHUT OFF	2790361	AR
1U1084	VALVE ASSY, DOOR	2131	AR
258000-3	PUMP, FUEL BOOSTER	0011021B	AR
382300-2	FUEL BOOSTER PUMP	1234A	AR
H10-1015-4	CONTROL SWITCH	7714	AR
898126-2-1	PRESS DIFF REGULATOR	P255	AR
30-0191-8-4174	LIGHT, NAV POSITION	7293	AR
DMNI50-2-2	ANTENNA	27499	AR
184380-1	EXCHANGER, HEAT PRECOOLER	53-1032	AR
793T100-7	ALTERNATE DRIVE UNIT WING FLAPS	5133	AR
320115	VALVE, AIR SHUTOFF	3378	AR
398542-2-1	VALVE, BUTTERFLY 35 DEG. CONTROL	P-10997	AR
MS28034-1	SENSOR, TEMPERATURE	42009	AR
70408-2	VALVE, HYD SHUTTLE	1263G	AR
7579078	FILTER, HYDRAULIC LINE	UNK	AR
7679078	FILTER HYDRAULIC LINE	UNK	AR
391046-172	TRANSMITTER, GAGE FUEL	3346N	AR
391046-170	TRANSMITTER, GAGE FUEL	13-7161	AR

10-60133-5	TEMP SENSOR	4643	AR
MS28034-1	SENSOR, TEMPERATURE	19865	AR
65-17819-12	ACTUATOR ASSEMBLY	D14001	AR
123552-1-4	VALVE, CHECK	8562	AR
10-60710-2	3 WAY VALVE	68023A	AR
69-17380-16	PANEL, CABIN ATTENDANT	UNK	AR
70408-2	VALVE, HYD SHUTTLE	H5391H	AR
65-17870-9	ASSY, HYDRAULIC RES	UNK	AR
70408-2	VALVE, HYD SHUTTLE	G985G	AR
1523107-103	ACTUATOR, NLG JURY BRACE	M0037	AR
40-533	WHEEL TRANSDUCER	962	AR
204185-3	CENTRIFUGAL TRUB COMPRESSOR	72-548	AR
1U1103-2	ACTUATOR, LEADING EDGE SLAT	34828BDFJLM3	AR
1060533-1	FUEL BOOSTER PUMP	1010920B	AR
1060533-1	FUEL BOOSTER PUMP	1010820B	AR
1356-603399	ACCUMULATOR, HYDRAULIC	7640	AR
392716-1-1	VALVE	P-3613	AR
65-17822-6	MODULAR PACKAGE ASSEMBLY	1542	AR
392914-1-1	PRESS REGULATOR	P1345	AR
65-23557	HYDRAULIC MOTOR	SLH36984	AR
65-17823-1	MODULAR PACKAGE ASSY FLIGHT CONTROL	1100	AR
21450-14	CYLINDER HYDRAULIC POWER CONTROL	338343	AR
258000-8	FUEL BOOSTER PUMP	101108B	AR
BAC27DCT-171	ACTUATOR, GROUND SPEED BRAKE	1025	AR
39-043A	PRESSURE CONTROL VALVE	13283	AR
65-235718	GEARBOX	UNK	AR
BAC27DCT-171	ACTUATOR, GROUND SPEED BRAKE	1016	AR
96774-18-1570-13	FLAP POSITION MOTOR	163	AR
6562	VALVE FUEL SHUT OFF	7505	AR
S-41422	GLIDE PATH ANTENNA	586	AR
2070122-0501	ANTENNA, COUPLER	8665	AR
3141602	AIR PRESSURE REGULATOR	1581AB	AR
30-0191-8-4174	LIGHT, NAV POSITION	7291	AR
2-520	TEST POWRE UNIT	986	AR
XW21181-15	MOTOR CONVERTER ASSEMBLY	DLM056	AR
21450-14	CYLINDER HYDRAULIC POWER CONTROL	4548177	AR
1060533-1	FUEL BOOSTER PUMP	1011238B	AR
21450-14	CYLINDER HYDRAULIC POWER CONTROL	369248A	AR
65-17826-5	MODULAR PACKAGE ASSY STANDBY	959	AR
500-0101-1	COFFEE MAKER TRAY	5794	AR
80111	FUEL SHUTOFF VALVE	6445	AR
32-2861-001	VALVE AIR SHUT OFF	11780964	AR
80111	FUEL SHUTOFF VALVE	3039	AR
7006628	LEAD CONTROLLER GENERATOR DRIVE	3623	AR
69-48593-9	SHAKER TEST	R00354	AR
473049	UNIT, FUEL SIMULATION	288F	AR
69-18150-15	PANEL, VALVE TRANSIT	NA	AR
124836	WATT VAR METER	74C3487	AR
SRDL-6D	PRESSURE INDICATOR	5866	AR
SLZ9145	VERTICAL SPEED INDICATOR	VY1618D	AR
75-0169-5	PANEL, ANNUNCIATOR GENERATOR SYSTEM	396	AR
711002-5	PANEL, SELECTOR	CB2597	AR

G-1133-1	LE FLAP-SLAT DISPLAY	451	AR
69-38451-8	WINDOW HEAT CONTROL	NA	AR
28000-17	REGULATOR, DILUTER DEMAND	4714	AR
705-7V4	GYRO HORIZON	13265	AR
2593564-919	ALTITUDE SELECT CONTROLLER	2120360	AR
75-0148-11	PANEL ANNUNCIATOR	1084	AR
69-23832-6	AUX POWER UNIT GENERATOR	UNK	AR
G-1162E	VHF NAVIGAOTR VHF COMM.	361	AR
124835	FREQUENCY METER	73F9059	AR
1618-1501	INDICATOR TEMP ELC RESISTANCE	B959	AR
69-31331-7	SWITCH	UNK	AR
522-1859-033	DISTANCE INDICATOR	1315	AR
LKCB-18018	FREQUENCY METER	486	AR
101014	TRIP & DATE ENCODER	2723	AR
G-1169	VHF NAVIGATOR VHF COMM	283	AR
614937-101	COMPASS SYSTEM RACK	123A	AR
346D-1B	PASSENGER ADDRESS	6426	AR
1011C	UNIT, OPERATING POWER	2727	AR
522-2450-115	VOR/ILS RECEIVER	17297	AR
2566A-30A	SENSOR AOA	910-117	AR
87001A	SPEAKER	697	AR
787-6211-003	TRANSPONDER ATC	4156	AR
65-60214-27E	FLIGHT INSTRUMENT ACCESSORY	R0022	AR
C-07202-2	SHAKER, STICK	3364	AR
S-6025-2	VALVE, LANDING GEAR SELECTOR	2172	AR
364404	HYDRAULIC PUMP	MX342605	AR
65-17822-6	MODULAR PACKAGE ASSEMBLY	1414	AR
392914-1-1	PRESS REGULATOR	P612	AR
392914-1-1	PRESS REGULATOR	P1268	AR
2021136-2	ACTUATOR ROTARY	113-7704	AR
1697EA	HYDRAULIC VALVE CONTROL	1557	AR
B-2700-14	FUEL SHUTOFF VALVE	5806	AR
391046-169	TRANSMITTER, GAGE FUEL	3289N	AR
391046-177	TRANSMITTER, GAGE FUEL	3306N	AR
1021136-1	ROTARY	13-7161	AR
B2700-14	VALVE ASSY, BRAKE METERING	10995	AR
749965	ASSEMBLY FUEL FILTER HOUSING	3R1756	AR
392914-1-1	PRESS REGULATOR	P651	AR
A-0643-089-A	HYDRAULIC MOTOR PACKAGE	MX252826D	AR
EA1065A-2371	HYDRAULIC RESERVIOR ASSY.	3653BDFJK4M	AR
9390148-1	AC MOTOR	L869	AR
398088-3-1	VALVE, FLOW CONTROL	P2299	AR
8-25455	DYNAVANE AIR CLEANER	2725	AR
8-25455	DYNAVANE AIR CLEANER	2856	AR
10-60713-1	MACHMETER	MT-1088	AR
2123-M-100	FLUSH SWITCH	UNK	AR
398088-3-1	VALVE, FLOW CONTROL	P-559	AR
393088-3-1	VALVE FLOW CONTROL	P797	AR
858720	VALVE, CHECK	ML7982	AR
65-40467-4	ACTUATOR, LOCK ASSY NL6	312	AR
F61C0058MI	VALVE, AIR SHUTOFF	5377	AR
382300-2	FUEL BOOSTER PUMP	4835A	AR

F61C0058MI	VALVE, AIR SHUTOFF	4569	AR
65-17813-2	ACTUATOR	RC1202	AR
10-60364	CONTROL VALVE HYDRAULIC	1518	AR
7505639	ASSEMBLY, FILTER	1184	AR
66-20153-1	ESSENTIAL POWER PANEL	UNK	AR
2-299	POWER SUPPLY TRANSF. RECTIFIER	1535	AR
65-54219-7	LANDING GEAR HANDLE	UNK	AR
321942-1-1	VALVE BUTTERFLY CONTROL	P-1390	AR
622-4096-001	PASSENGER ADDRESS	5199	AR
65-52803-8	WINDOW HEAT CONTROL	R02171	AR
65-52804-77	AUDIO ACCESSORY UNIT	R00323	
2588145	FLIGHT DIRECTOR COMPUTER	7100446	AR
65-60214-153	FLIGHT INSTRUMENT ACCESSORY	R00 385	AR
522-2703-011	ATC TRANSPONDER	3114	AR
2588302-4	DIRECTIONAL GYROSCOPE	7122977	AR
166014	TRANSDUCER PRESSURE RATIO	2-62-	AR
522-2996-011	MARKER BEACON RECEIVER	4D14	AR
75-0039-7	PANEL ANNUNCAITOR	327	AR
2021136-2	ACTUATOR ROTARY	33-7390	AR
2588302-4	DIRECTIONAL GYROSCOPE	8049650	AR
398542-2-1	VALVE, BUTTERFLY 35 DEG. CONTROL	P-10142	AR
522-3073-012	COURSE INDICATOR	1379	AR
1784460	COMPASS INDICATOR	6060611	AR
2070945-4301	VHF TRANSCIEVER	2226	AR
2067157-0103	RADAR TRANS RECEIVER	S38S	AR
10-60757-7	POSITION INDICATOR	569	AR
700662A	LOAD CONTROLLER GENERATOR DRIVE	2132	AR
A4304910004	ALTIMETER SERVO INDICATOR	3268	AR
102518-7-1	CONTROL OUTFLOW VALVE	109-1474	AR
10-3257-5	POWER SUPPLY TRANSF RECTIFIER	2270	AR
2067593-2662	VHF NAV RECEIVER	3052	AR
777-1492-004	RECEIVER ADF	10118	AR
65-52803-8	WINDOW HEAT CONTROL	6570203	AR
10-3257-3	POWER SUPPLY TRANSF RECTIFIER	4765	AR
65-52803-8	WINDOW HEAT CONTROL	C671101	AR
65-52803-8	WINDOW HEAT CONTROL	89	AR
522-2996-011	MARKER BEACON RECEIVER	9012	AR
2588880-902	YAW ADAPTER COUPLER	811223	AR
562P-1	STEERING COMPUTER PITCH	1111	AR
2-301-3	BATTERY CHARGER	3	AR
G-3888	ADF CONTROL	14	AR
28000-1	OXYGEN REGULATOR	2573	AR
231-2	WINDOW HEAT CONTROL	1968	AR
902F283-2	BUS PROTECTION PANEL	RS776	AR
822-3375-004	CONTROL ANTENNA COUPLER	627	AR
787-6211-003	TRANSPONDER ATC	4152	AR
622-3179-004	RECEIVER ADF	1988	AR
522-2788-015	MONITOR COMPARATOR WARN	842	AR
965-0376-068	COMPUTER GPWC	275	AR
2-299	POWER SUPPLY TRANSF. RECTIFIER	3543	AR
69-25893-1	CABIN TEMPERATURE CONTROL	UNK	AR
G-1164-E	ANT STABILIZER	316	AR

422-3375-004	CONTROL ANTENNA COUPLER	659	AR
902F242-5	ELECTRICAL SYSTEM PANEL PROTECTION	NM2402	AR
700864	STROBE ALERT	AG0002	AR
28000-1	OXYGEN REGULATOR	8122	AR
522-4114-003	RADIO INDICATOR	3898	AR
614E-9C	FLIGHT DIRECTOR CONTROL	1180	AR
PPI-IG	INDICATOR	2551	AR
C28GK23471(A)	FUEL BOOSTER PUMP	UNK	AR
10-60757-28	TEMPERATURE INDICATOR	7367152	AR
JG28846	INDICATOR, PRESSURE RATIO	A-376	AR
2589210	COMPASS SYSTEM RACK	80053055	AR
2587335-11	VERTICAL GYRO	7011780	AR
080-20325-01	POWER SUPPLY TRANSF. RECTIFIER	2006	AR
522-4280-109	VOR/ILS RECEIVER	7F13734	AR
10-60922-5	AIRSPEED INDICATOR & TRANSMITTER	588-A	AR
27755	ROTARY ACTUATOR	82-5153	AR
562R-1	STEERING COMPUTER ROLL	554	AR
93-A100-80	COCKPIT VOICE RECORDER	4089	AR
162BL704D	TEMPERATURE INDICATOR	A36	AR
522-2996-011	MARKER BEACON RECEIVER	2407	AR
522-4538-002	PASSENGER ADDRESS	118	AR
840327	PNEUMATIC SYSTEM	1820	AR
DLH41841	SLIDER	UNK	AR
G-1165	NAVIGATION PANEL	172	AR
69-17400-7	ENGINE START PANEL	UNK	AR
2585802-12	CONTROL PANEL	521760	AR
A88Y69-38451-13	WINDOW HEAT CONTROL	23490	AR
743602-5	ENGINE CONTROL	A1759	AR
743602-5	ENGINE CONTROL	68445	AR
LG14C14	TRANSDUCER PRESURE RATIO	P117	SV
743602-5	ENGINE CONTROL	65598	AR
976J119-8	GENERATOR, AC	YG2036	AR
976J598-1	GENERATOR, AC	TN960M	AR
976J598-1	GENERATOR, AC	OR3088	AR
976J598-1	GENERATOR, AC	YM264	AR
357-0087	PANEL, WATER QUANTITY	16	AR
69-47105-301	LANDING GEAR PANEL	UNK	AR
69-16268-8	PANEL	UNK	AR
69-17529-18	FREQUENCY BOARD	UNK	AR
A16704-1	ALTERNATE FLAPS PANEL	UNK	AR
69-66571-12	PANEL, FIRE #1 AND #2	M00025	AR
6430A	PANEL, SWITCH	31348	AR
69-20463	WING ANIT-ICE PANEL	UNK	AR
G-5542	PANEL	8	AR
G-1341A-1	PANEL	115	AR
69-66589-21	PANEL, FIRE#3	M00048	AR
G-3816	FAULT REPLY PANEL	182	AR
69-17379-34	MAIN GEAR ANTI SKID PANEL	UNK	AR
69-17380-9	CABIN ATTENDANT PANEL	UNK	AR
69-18150-15	PANEL, VALVE TRANSIT	UNK	AR
69-17529-18	FREQUENCY BOARD	UNK	AR
LG14C14	TRANSDUCER PRESURE RATIO	F231	SV

10-61926-3	FLAP POSITION INDICATOR	312	AR
163BL501	TEMPERATURE INDICATOR	H2493	AR
163BL501	TEMPERATURE INDICATOR	142060	AR
G-2906E	OXYGEN MASK MIC	144	AR
162BL504	TEMP ELECTRICAL RESISTANCE INDICATOR	F158	AR
2588838	POSITION SENSOR	230516	AR
69-17525-1	ANTI-ICE PANEL	UNK	AR
8DJ88	INDICATOR; RATE OF FLOW, FUEL	PT405	AR
SLZ9145	VERTICAL SPEED INDICATOR	VY2028D	AR
28000-1	OXYGEN REGULATOR	9428	AR
A4304910004	ALTIMETER SERVO INDICATOR	242B	AR
33-PA-427	PANEL ANNUNCIATOR	1186	AR
393026-042	TRANSISTORIZED AMPLIFIER/ IND. BRIDGE	M1471C	AR
2566A-30	ANGLE OF AIRFLOW SENSOR	925-4	AR
260582	ELEVATOR AND RUDDER INDICATOR	452	AR
10-60757-128	OIL TEMP INDICATOR	202	AR
392688-1-1	VALVE	80268	AR
2021134	ROTARY ACTUATOR	331	AR
30-0191-7	LIGHT ASSY, NEW POSITION	NA	AR
ST-7R	PRESSURE HYDRAULIC	8011	AR
69-24433-3	ASSY, LANDING LIGHT	UNK	SV
B0707-10007	SENSOR, OVERSPEED LIMIT	3693	SV
525374	ROTARY ACTUATOR	98-3021	AR
ST-7R	PRESSURE HYDRAULIC	8011	SV
162BL704D	TEMPERATURE INDICATOR	A188	AR
700662A	LOAD CONTROLLER GENERATOR DRIVE	2372	AR
393020-01789	TRANSISTORIZED AMPLIFIER	89149	AR
162BL701	TEMPERATURE INDICATOR	16	AR
69-15974-3	FLIGHT RECORDER	UNK	AR
69-19228-10	OIL COOLER CSD INDICATOR	88072001	AR
39-3084-04359	TRANISTONZED AMP	557B	AR
69-58212-1	SPEED COMMAND TEST INDICATOR	UNK	AR
10-60518-11	CONTROL BOX HYTROOL MARK II	1226	AR
40057-1	SWITCH, FUEL PRESSURE	24997	AR
MS28034-1	SENSOR, TEMPERATURE	13186	AR
A3811910008	ALTMETER PRESSURE	1965	AR
3000-46-2	SENSOR, TEMPERATURE	507	AR
69-244-33-3	LANDING LIGHT	NA	AR
80111	FUEL SHUTOFF VALVE	1823	AR
10-61329-11	MOTOR, WINDSHIELD WIPER	54672	AR
LG-14C14	TRANSDUCER, PRESSURE RATIO	E-20-DLH	AR
522-3073	COURSE INDICATOR	184	AR
614E-9C	FLIGHT DIRECTOR CONTROL	673	AR
40057-1	SWITCH, FUEL PRESSURE	21012	AR
10-60872-1	RATE OF CLIMB SWITCH	1395-M	AR
XW20345	MOTOR, WINDSHIELD WIPER	UNK	AR
69-17270-40	FUEL BOOSTER PUMP	12	AR
8SAT	PITOT TUBE	93532	AR
2575570-902	MASTER FLUX VALVE	78079179	AR
124832	A.C. VOLTMETER	7386157	AR
MS28034-1	SENSOR, TEMPERATURE	27355	AR
152BL01E	INDICATOR, EXHAUST, GAS, TEMP	1171	AR

SRL-04L	INDICATOR, OIL PRESSURE	7276	AR
10184E	VALVE ASSY DOOR OPERATED GEAR		AR
65-21945-5	GEARBOX	DHL41720	AR
B711-1	INDICATOR HYD. OIL QTY.	B0276	AR
40057-1	SWITCH, FUEL PRESSURE	UNK	AR
8DJ81	INDICATOR; ELECTRICAL TACHOMETER	B8725	AR
124R36	WATT-VAR METER	7367325	AR
6562	VALVE FUEL SHUT OFF	7512	AR
393026-03236	TRANSISTORIZED AMPLIFER	M9003G	AR
124836	WATT VAR METER	73G7321	AR
10-60887-2	OXYGEN REGULATOR	11664	AR
G-5729EA	PITOT STATIC HEATER MONITOR	69	AR
10-60757-128	OIL TEMP INDICATOR	8030	AR
522-0700-003	ANTENNA, GLIDE SLOPE	8473	AR
1060533-3	FUEL BOOSTER PUMP	644	AR
65-17823	MODULAR PACKAGE ASSY	1549	AR
A4144910006	AIRSPEED INDICATOR & TRANSMITTER	13633	AR
1060533-1	FUEL BOOSTER PUMP	100855AB	AR
1011B	OPERATING POWER UNIT	2205	AR
8SIT	PITOT TUBE	93533	AR
32-2861-001	VALVE AIR SHUT OFF	89-90	AR
G-9325A-1	LIGHT ASSEMBLY, ANIT-COLLISION BEACON	5795	AR
541248-3	ROTARY ACTUATOR	52-2170	AR
392716-1-1	VALVE	P-3409	AR
F61C0058M1	VALVE, AIR SHUTOFF	5644	AR
321942-1-1	VALVE BUTTERFLY CONTROL	P-1577	AR
F61C0058M1	VALVE, AIR SHUTOFF	3987	AR
BAC-M10L-10-1BXK	DAMPNER	UNK	AR
398542-2-1	VALVE, BUTTERFLY 35 DEG. CONTROL	P-7504	AR
123674-1-1	CHECK VALVE	P-2439	AR
2575570	FLUX VALVE	87098055	AR
MS28034-1	SENSOR, TEMPERATURE	11575	AR
XW23827-1	ELECTRIC MOTOR	A1767	AR
2-520	TEST POWRE UNIT	859	AR
33-SW1597	SENSOR, TEMPERATURE	65	AR
384453-00	TRANSISTORIZED VOLUMETRIC	6881AC	AR
69-48598-24	ENGINE BLEED PANEL	UNK	AR
966-0021-003	FLAT POSITION STALL WARNING SPEED COM	203	AR
B712-4	IND. HYD. OIL QTY.	B4399-18	AR
3000-46-2	SENSOR, TEMPERATURE	4366	AR
966-0022-001	TRANSMITTER, FLAP POSITION	UNK	AR
XW23827-1	ELECTRIC MOTOR	A6838	AR
MS28034-1	SENSOR, TEMPERATURE	44884	AR
1011B	OPERATING POWER UNIT	2416	AR
3000-46-2	SENSOR, TEMPERATURE	4346	AR
3000-46-2	SENSOR, TEMPERATURE	2979	AR
1775EA	CONTROL VALVE- HYDRAULIC	1221	AR
22504-7	ELECTRO PNEUMATIC CONTINOUS FLOW CON	2473	AR
6574	ACTUATING HANDLE ASSEMBLY	1709	AR
22505-7	PNEUMATIC CONTINOUS FLOW CONTROL	228	AR
321942-1-1	VALVE BUTTERFLY CONTROL	P-2515	AR
69-48593-8	STALL WARNING	332	AR

G-2906E	OXYGEN MASK MIC	150	AR
H10-1027-1	SWITCH, ROTARY	G00070	AR
7-7050-1	START VALVE INDICATOR PANEL	102	AR
30-0191-8	LIGHT ASSY, NEW POSITION	UNK	AR
1775EA	CONTROL VALVE- HYDRAULIC	1205	AR
69-17379-21E	NOSE GEAR BRAKE PANEL	13218	AR
384453-001	TRANSISTORIZED VOLUMETRIC	6088	AR
AV13J5101	3 WAY VALVE	965991A	AR
382300-2	FUEL BOOSTER PUMP	2456A	AR
65-17978	SWIVEL ASSEMBLY	DA1218	AR
109644-M1-1	VALVE, BUTTERFLY	P-2879	AR
344C-1K	INSTRUMENT AMPLIFIER	2187	AR
65-52803	WINDOW HEAT CONTROL	B00637	AR
65-52803-8	WINDOW HEAT CONTROL	D00086	AR
522-2450-114	VOR/ILS RECEIVER	1203	AR
2585800	GYRO YAW PAM COUPLER	630143	AR
65-60210-32	AUDIO ACCESSORY UNIT	M00077	AR
970620-200	INSTRUMENT SWITCHING UNIT	373	AR
97619-300	RADIO NAV. SWITCHING UNIT	188	AR
ASS469-17270-25	BOOST PUMP CONTROL	UNK	AR
6577-1	VANEAXIAL FAN	2278	AR
ST-106AB	TRANSMITTER, PRESSURE	1111	AR
851T	PITOT	83531	AR
2586103-1	YAW RACK	1011665	AR
65-60211-32	LANDING GEAR ACCESSORY	R0008	AR
204185-3	CENTRIFUGAL TRUB COMPRESSOR	10-1407	AR
69-64387-3	LIGHT ASSY, LANDING	UNK	AR
G-1169	VHF NAVIGATOR VHF COMM	334	AR
6562	VALVE FUEL SHUT OFF	7289	AR
3360	VALVE FUEL SHUT OFF	4519	AR
2021136-2	ACTUATOR ROTARY	73-759	AR
77AT141	VALVE SHUT OFF GATE	A43370068	AR
6562	VALVE FUEL SHUT OFF	2820	AR
393026-042	TRANSISTORIZED AMPLIFIER/ IND. BRIDGE	127	AR
40-533	WHEEL TRANSDUCER	5875	AR
10-60757-23	DC VOLTMETER ACTUATING HANDLE ASSY	773792	AR
65-17978	SWIVEL ASSEMBLY	DA1966	AR
384453-001	TRANSISTORIZED VOLUMETRIC	5342W	AR
21450-1	CYLINDER HYDRAULIC POWER CONTROL	343964	AR
BAC27DCT-171	ACTUATOR, GROUND SPEED BRAKE	249	AR
40-533	WHEEL TRANSDUCER	6095	AR
40-533	WHEEL TRANSDUCER	2567	AR
89-125-2	REGULATOR PRESS DIFF.	B-12-83	AR
40-533	WHEEL TRANSDUCER	3538	AR
69-17313-8	HYDRAULIC POWER CONTROL PANEL	UNK	AR
9-25105-14	OXYGEN MASK MIC	UNK	AR
Y-555808-7024R	FUEL BOOSTER PUMP	10110208	AR
6562	VALVE FUEL SHUT OFF	7297	AR
5552	VALVE FUEL SHUT OFF	2964	AR
522-4114-003	RADIO INDICATOR	6556	AR
966-0022-001	TRANSMITTER, FLAP POSITION	1651	AR
693086-01238	TRANSISTORIZED AMPLIFIER & INDICATOR	9874	AR

65-17823	MODULAR PACKAGE ASSY	81101	AR
65-17813-2	ACTUATOR	RC1138	AR
30-0191-8	LIGHT ASSY, NEW POSITION	72914	AR
392716-1-1	VALVE	F-101	AR
65-17826-7	MODULAR PACKAGE ASSY	1018	AR
65-17821-8	MODULAR PACKAGE ASSY	1128A	AR
65-17978-22	VALVE	326	AR
69-15971-12	FUEL VALVE CONTROL PANEL	M0018	AR